SHARP PARTS GUIDE

MODEL AR-RF2

このパーツガイドに掲載されている表示価格ランクは消費税抜きです。

CONTENTS

1 外装部(Exteriors)
2 搬送ﾍﾞﾙﾄ部(Transport belt section)
3 給紙搬送部 1 (Paper feeding transport section 1)
4 給紙搬送部 2 (Paper feeding transport section 2)
5 反転搬送部 (Reversion transport section)
7 給紙ﾄﾚｲ部 (Paper feedig tray section)
8 梱包材＆付属品 (Packing material & Accessories)
9 PBA-ｺﾝﾄﾛｰﾙ基板(PBA-Control PWB)
■ 索引(Index)

補修部品のランク付

市場における補修部品の在庫管理が、適正に運営出来る手助けとなることを、目的とします。

Aランク ： 取替頻度が比較的多く、在庫を必要とするパーツ。
Bランク ： 取替頻度は比較的少ないが、在庫を必要とするパーツ。
Cランク ： 取替頻度はほとんどないと思われるパーツ。
Dランク ： 取替頻度はほとんどないが新品再生に必要なパーツ。
Eランク ： ユニットパーツ。サービス効率アップの為、在庫する事を推奨するパーツ。
Sランク ： 消耗品

但し、複写機のパーツについては、同一パーツ名であっても、下記パーツは、使用箇所の相違により、A・Bランク分けし ます。

パーツ名 ： 金属製のギャー、スプロケット、ベアリング、ゴム製のベルト、スプリングクラッチ機構
Aランク ： 常に回転しているか、付加がかかっている箇所に使用され、回転回数が増える事により、変形又は磨耗が生じその性能が発揮できなくなるパーツ。
Bランク ： 回転部分に使用されているが、磨耗度が比較的少ないパーツ。

安全性・信頼性確保のため部品は、必ず正規のものをご使用下さい。
⚠印の商品は、安全上重要な部品です。交換をする時は、安全および性能維持のため必ず指定の部品をご使用下さい。

○ 当モデルのサービス資料には、この資料以外にサービスマニュアル（回路図含む）があります。合わせて御利用下さい。

DEFINITION

The definition of each Rank is as follows and also noted in the list

A : Parts necessary to be stocked as High usage parts.
B : Parts necessary to be stocked as Standard usage parts.
C : Low usage parts.
D : Parts necessary for refurbish.
E : Unit parts recommended to be stocked for efficient after sales service.
Please note that the lead time for the said parts may be longer than normal parts.
S : Consumable parts.

Please note that the following parts used in Copier under the same description are classified into A or B Rank depending upon the place used.

Example : Gear made of Metal, Sprocket, Bearing, Belt made of Rubber, Spring clutch mechanism.
A Rank : The parts which may be with the revolution or loading.
B Rank : Parts similar to A Rank parts, but are not included in Rank A.

Because parts marked with "⚠" is indispensable for the machine safety maintenance and operation, it must be replaced with the parts specific to the product specification.

○ Other than this Parts Guide, please refer to documents Service Manual (including Circuit Diagram) of this model.
○ Please use the 13 digit code described in the right hand corner of front cover of the document, when you pleace an order.
○ For U.S. only-Use order codes provided in advertising literature. Do not order from parts department.

本書はサービス活動用に作成した資料です。
一部内容が製品の改良・改善等により予告なしに変わることがあります。

SHARP CORPORATION

This document has been published to be used for after sales service only.
The contents are subject to change without notice.

1 外装部(Exteriors)

NO.	PARTS CODE	PRICE RANK		NEW MARK	PART RANK	DESCRIPTION	
		Ex.	Ja.				
1	0CW2214K326//	BS	MJ		E	DF cover sub ass'y	DF ｶﾊﾞｰｻﾌﾞｸﾐ (C)
2	0CW2214P127//	AR	EQ		C	Lower cover	ｼﾀｶﾊﾞｰ
3	0CW2214K344//	BD	GN		E	Hinge R ass'y	ﾋﾝｼﾞ Rｸﾐ
4	0CWE450000433	AB	DD		C	Edge saddle 1 (EDS-1)	ｴｯｼﾞｻﾄﾞﾙ1
5	0CW2234P104//	AG	DS		C	Hinge stopper	ﾋﾝｼﾞｽﾄｯﾊﾟｰ
6	0CWE450000070	AB	DJ		C	Wire clamp (NK-5N)	ﾜｲﾔｰｸﾗﾝﾌﾟ
⚠ 7	0CW2214K240//	BE	GN		B	ASM-IF-CG-A-harness	ASM-IF-CGﾊｰﾈｽ-A
8	0CW2214K054//	AH	DX		C	Tension plate ass'y	ﾃﾝｼｮﾝｲﾀｶｼﾒｸﾐ
9	0CW2214P350//	AD	DJ		C	Belt tension spring	ﾍﾞﾙﾄﾃﾝｼｮﾝｽﾌﾟﾘﾝｸﾞ
10	0CW2214P110//	AL	EB		C	DF motor bracket	DFﾓｰﾀｰﾌﾞﾗｹｯﾄ
11	0CW2214P315//	AR	EQ		C	Pulley (PLY-S2M-24)	ﾌﾟｰﾘｰ
12	0CW2223P404//	BN	HZ		B	Motor (MOT-KH56KM2-017)	ﾓｰﾀｰ
13	0CWE120000870	AM	EG		B	Microswitch (SS-5T)	ﾏｲｸﾛｽｲｯﾁ
14	0CW2214P126//	AG	DX		C	DF earth plate spring	DFｱｰｽｲﾀﾊﾞﾈ
15	0CW2214P117//	AF	DS		C	DF open switch plate	DFｵｰﾌﾟﾝSWｲﾀ
16	0CW2214P513//	AG	DS		C	Hinge earth plate spring	ﾋﾝｼﾞｱｰｽｲﾀﾊﾞﾈ
17	0CW2234K034//	BD	GN		E	Hinge L ass'y	ﾋﾝｼﾞ Lｸﾐ
18	0CW2214P135//	AE	DJ		C	Interface plate	ﾁｭｳｹｲﾌﾟﾚｰﾄ
19	0CW2214K208//	AS	EQ		C	ASM-drive interface harness	ASM-ﾄﾞﾗｲﾌﾞﾁｭｳｹｲﾊｰﾈｽ
20	0CW2214K200//	AP	EQ		C	ASM-TR1 harness	ASM-TR1ﾊｰﾈｽ
21	0CW2214K203//	AN	EG		C	ASM-SNR harness	ASM-SNRﾊｰﾈｽ
22	0CW2214K206//	AN	EG		C	ASM-sensor interface harness	ASM-ｾﾝｻｰﾁｭｳｹｲﾊｰﾈｽ
23	0CW2214P068//	AM	EG		D	Mentenance cover	ﾒﾝﾃﾅﾝｽｶﾊﾞｰ(C)
24	0CWE4500000368	AD	DJ		C	Clamp (T18MR)	ｸﾗﾝﾌﾟ
25	0CWE450000071	AC	DJ		C	Wire clamp (NK-6N)	ﾜｲﾔｰｸﾗﾝﾌﾟ
26	0CW2214P140//	AE	DJ		C	M plate	Mﾌﾟﾚｰﾄ
27	0CW2234K222//	CA	TX	N	E	PBA control PWB	PBA-ｺﾝﾄﾛｰﾙ-Cｷﾊﾞﾝ
28	0CW2214P136//	AG	DS		C	Delivery collar plate spring	ﾊｲｼｺﾛｲﾀﾊﾞﾈ
29	0CW2214P116//	AE	DJ		C	DF fixing plate (100V series)	DFｺﾃｲﾌﾟﾚｰﾄ
	0CW2217P135//	AG	DS		C	DF fixing plate (200V series)	DFｺﾃｲﾌﾟﾚｰﾄ
30	0CW2214K205//	AL	EB		C	ASM-LED harness	ASM-LEDﾊｰﾈｽ
31	0CW2214K223//	AU	EZ		E	PBA-LED PWB	PBA-LEDｷﾊﾞﾝ
32	0CW040060FZTP	AA	DD		C	Screw (4×6)	ITﾀｯﾌﾟﾀｲﾄﾈｼﾞ
33	0CW040040FZiT	AA	DD		C	Screw (4×4)	ITﾈｼﾞ
34	0CW030060FZTP	AA	DD		C	Screw (3×6)	ITﾀｯﾌﾟﾀｲﾄﾈｼﾞ
35	0CW040080FNBi	AA	DD		C	Screw (4×8)	ﾊﾞｲﾝﾄﾞﾈｼﾞ
36	0CW2106P091//	AC	DJ		C	Screw	D ﾀﾞﾝﾋﾟｽ 1.2
37	0CW040060FNBi	AA	DD		C	Screw (4×6)	ﾊﾞｲﾝﾄﾞﾈｼﾞ
38	0CW030060FZWS	AA	DD		C	Screw (3×6)	Wｾﾑｽﾈｼﾞ
39	XRESP20-04000	AA	DD		C	E type ring	Eﾘﾝｸﾞ (ER020SKP)
40	0CW040080FZBi	AA	DD		C	Screw (4×8)	ﾊﾞｲﾝﾄﾞﾈｼﾞ
41	0CW040060FPWP	AA	DD		C	Screw (4×6)	6ｶｸｱﾅﾂｷﾈｼﾞ
42	0CW023120FBWS	AB	DJ		C	Screw (2.3×12)	Wｾﾑｽﾈｼﾞ
43	0CW812531////	AA	DD		C	Screw (3×8)	ﾈｼﾞ
44	0CW1001P441//	AG	DX		C	Bolt (3×6)(BOT-SW-HW CAP)	ﾎﾞﾙﾄ
45	0CW2185P359//	AB	DJ		C	Screw (4×12)	ｳｪｰﾌﾞｽｸﾘｭｰ
46	0CW030080FZBB	AB	DJ		C	Screw (3×8)	Bﾀｲﾄﾈｼﾞ
47	0CW2185P358//	AB	DJ		C	Screw (4×8)	ｳｪｰﾌﾞｽｸﾘｭｰ
48	0CW030100FBBB	AB	DJ		C	Screw (3×10)	Bﾀｲﾄﾈｼﾞ
49	0CW2224P334//	AS	EQ		D	Display panel (Japan only)	ﾋｮｳｼﾞﾊﾟﾈﾙ
	0CW2224P333//	AN	EG		D	Display panel LN (Except Japan)	ﾋｮｳｼﾞﾊﾟﾈﾙLN
50	0CW2095P053//	AE	DJ		C	Flange A	ﾌﾗﾝｼﾞ A
51	0CW2214P453//	AD	DJ		C	Delivery collar sheet	ﾊｲｼｺﾛﾏｲﾗｰ
52	0CW2166P265//	AF	DS		C	Spacer rubber	ｽﾍﾟｰｻｰｺﾞﾑ
53	0CW2158P003D/	AF	DS		C	Switch lever	SWﾚﾊﾞｰ
54	0CW2214P512//	AG	DX		C	Hinge cover	ﾋﾝｼﾞｶﾊﾞｰ
55	0CW2168P010//	AF	DS		C	R tension collar	Rﾃﾝｼｮﾝｶﾗｰ
56	0CW2221P336//	AU	EZ		C	Protect rubber	ﾎﾞｳｼﾝｺﾞﾑ
58	0CW2214P496//	AE	DJ		C	A damper sheet W	AｼｮｳｵﾝｼｰﾄW
59	0CW2214P497//	AE	DJ		C	A damper sheet S	AｼｮｳｵﾝｼｰﾄS
60	0CW2214P489//	AH	DX		C	Protect sheet L	ﾎﾞｳｵﾝｼｰﾄL
61	0CW2214P490//	AG	DX		C	A side plate R damper	AｿｸﾊﾞﾝRﾀﾞﾝﾊﾟｰ
62	0CW2158P504//	AK	EB		C	Rubber support	ｺﾞﾑｻﾎﾟｰﾄ
63	0CW040060FZWS	AA	DD		C	Screw (4×6)	Wｾﾑｽﾈｼﾞ
64	0CW2214P498//	AE	DJ		C	Stopper cushion 4	ｽﾄｯﾊﾟｰｸｯｼｮﾝ4
65	0CW2180P333//	AC	DJ		C	Screw (3×6)	Mﾀｯﾌﾟﾀｲﾄﾈｼﾞ
67	0CWE240000309	AP	EQ		B	Core (044S-665802)	ﾌｪﾗｲﾄｺｱ
68	0CW2205P042//	AD	DJ		C	Delivery collar	ﾊｲｼｺﾛ
69	0CW2144P409//	AB	DJ		C	Screw (3×6)	ﾓｰﾙﾄﾞBPﾈｼﾞ
70	0CW030030FNiT	AB	DJ		C	Screw (3×3)	ﾋﾞｽ
71	0CW2078P119B/	AB	DD		C	Screw 3.2 (M3)	M3ﾀﾞﾝﾋﾞｽ 3.2
77	0CWE74382WE03	AL	EB		C	CT-interface connector	CT-ﾁｭｳｹｲｺﾈｸﾀｰ
78	0CW2234K203//	AG	DS		C	ASM-earth wire SG	ASMｱｰｽｾﾝSG
79	0CWE240000356	AS	EQ		C	Feright core (ZCAT-2035-0930A)	ﾌｪﾗｲﾄｺｱ
501	0CW2214K217//	AU	EZ		C	ASM-TR1-C harness	ASM-TR1-Cﾊｰﾈｽ

1 外装部(Exteriors)



2 搬送ﾍﾞﾙﾄ部(Transport belt section)



2 搬送ﾍﾞﾙﾄ部(Transport belt section)

NO.	PARTS CODE	PRICE RANK		NEW MARK	PART RANK	DESCRIPTION	
		Ex.	Ja.				
1	0CW2214P114//	AK	DX		C	MG catch holder	MGｷｬｯﾁﾎｳｹ
2	0CW2214P111//	AS	EQ		C	DF side plate F	DFｿｸﾊﾞﾝF
3	0CW2214P043//	AD	DJ		C	DF spacer L	DFｽﾍﾟｰｻｰL
4	0CW2214P044//	AF	DS		C	Belt guide	ﾍﾞﾙﾄｶﾞｲﾄﾞ
5	0CW2214P138//	AH	DX		C	Belt tension plate F	ﾍﾞﾙﾄﾃﾝｼｮﾝﾌﾟﾚｰﾄF
6	0CW2214P042//	AD	DJ		C	DF spacer R	DFｽﾍﾟｰｻｰR
7	0CW2214P575//	BR	LP	N	B	DF belt (CGR)	DFﾍﾞﾙﾄ
9	0CW2214P141//	AH	DX		C	Fixer collar plate spring	ｵｵｴｺﾛｲﾀﾊﾞﾈ
10	0CW2214P118B/	AM	EG		C	Fixer collar stay S	ｵｻｴｺﾛｽﾃｲS
11	0CW2214P462//	AZ	FQ		C	Roller SHP	ｵﾄｼﾛｰﾗｰSHP
12	0CW2214P322//	BB	GD		C	Belt roller L	ﾍﾞﾙﾄﾛｰﾗｰL
13	0CW2214P112//	AW	FG		C	DF side plate R	DFｿｸﾊﾞﾝR
14	0CW2214P139//	AH	DX		C	Belt tension plate R	ﾍﾞﾙﾄﾃﾝｼｮﾝﾌﾟﾚｰﾄR
15	0CW030060FZSW	AA	DD		C	Screw (3×6)	Wｾﾑｽﾈｼﾞ
16	0CW4016P167//	AC	DJ		C	Screw (SCR030050)	ﾈｼﾞ
17	0CW030060FZTP	AA	DD		C	Screw (3×6)	ITﾀｯﾌﾟﾀｲﾄﾈｼﾞ
18	XRESP70-08000	AA	DD		C	E type ring	Eﾘﾝｸﾞ (ER070SKP)
19	0CW030060FNTP	AB	DJ		C	Screw (3×6)	ITﾀｯﾌﾟﾀｲﾄﾈｼﾞ
20	0CW030080FZWS	AA	DD		C	Screw (3×8)	Wｾﾑｽﾈｼﾞ
21	0CW2078P023B/	AC	DJ		C	Screw 1.4 (M3)	M3ﾀﾞﾝﾋﾞｽ 1.4
22	0CW030060FZWS	AA	DD		C	Screw (3×6)	Wｾﾑｽﾈｼﾞ
23	0CW650593////	AU	EZ		B	Bearing (BRG-LF-1280ZZ)	ﾍﾞｱﾘﾝｸﾞ
24	0CW2214P393//	AG	DX		B	Magnet catch 13N	ﾏｸﾞﾈｯﾄｷｬｯﾁ13N
25	0CW2214P393//	AG	DX		B	Magnet catch 13N	ﾏｸﾞﾈｯﾄｷｬｯﾁ13N
26	0CW2205P360//	AD	DJ		C	Roller spring	ｵﾄｼﾛｰﾗｰﾊﾞﾈ
27	0CW2164P142//	AF	DS		C	Belt roller spring holder	ﾍﾞﾙﾄﾛｰﾗｰﾊﾞﾈｳｹ
28	0CW2214P051//	AD	DJ		C	Holder S	ｵﾄｼﾎﾙﾀﾞｰS
29	0CW2160P344//	AR	EQ		B	Bearing (BRG8-16)	ﾍﾞｱﾘﾝｸﾞ
30	0CW2185P023//	AE	DS		B	A belt pulley 30	Aﾍﾞﾙﾄﾌﾟｰﾘｰ30
31	0CW2214P321//	BB	GD		C	Belt roller R	ﾍﾞﾙﾄﾛｰﾗｰR
33	0CW2205P351//	AU	EZ		C	Belt fixing roller	ﾍﾞﾙﾄｵｻｴﾛｰﾗｰ
34	0CW2158P035A/	AD	DJ		C	Fixing collar	ｵｻｴｺﾛ
35	0CW2205P037//	AE	DJ		C	Fixing holder	ｵｻｴﾎﾙﾀﾞｰ
36	0CW2205P025//	AD	DJ		C	Pressure spacer	ｱﾂｾﾂｽﾍﾟｰｻｰ
37	0CW2205P147//	AC	DJ		C	Fixing roller spring	ｵｻｴﾛｰﾗｰﾊﾞﾈ
38	0CW2205P147//	AC	DJ		C	Fixing roller spring	ｵｻｴﾛｰﾗｰﾊﾞﾈ
39	0CW2214P157//	AK	DX		C	Fixing collar plate spring L	ｵｻｴｺﾛｲﾀﾊﾞﾈL
40	0CW2214P520//	AU	EZ		C	Fixing holder	ｵｻｴﾎﾙﾀﾞｰ
41	0CW030060FZiT	AA	DD		C	Screw (3×6)	ITﾈｼﾞ
42	0CWZ0030WE004	AC	DJ		C	Ege saddle (CE-012S)	ｴｯｼﾞｻﾄﾞﾙ
43	0CW2214P149//	AG	DX		C	MG earth plate	MGｱｰｽｲﾀﾊﾞﾈ
44	0CW2214P569//	AB	DJ		C	Screw M3	M3ﾀﾞﾝﾋﾞｽ
45	0CW2234P410//	AR	EQ		C	Gasket 2234 (200V series)	ｶﾞｽｹｯﾄ2234
46	0CW2198P305//	AH	DX		C	Fixing coller H	ｵｻｴｺﾛ H

3 給紙搬送部1(Paper feeding transport section 1)

NO.	PARTS CODE	PRICE RANK		NEW MARK	PART RANK	DESCRIPTION	
		Ex.	Ja.				
1	0CW2214P037//	AH	DX		C	Harness guide	ﾊｰﾈｽｶﾞｲﾄﾞ
2	0CW2214K209//	AR	EQ		C	ASM-drive F harness	ASM-ﾄﾞﾗｲﾌﾞFﾊｰﾈｽ
3	0CW2214P405//	AD	DJ		C	SP tube 1	SPﾁｭｰﾌﾞ1
4	0CW2214K204//	AH	DX		C	ASM-sensor 1 harness	ASM-ｾﾝｻｰ1ﾊｰﾈｽ
⚠ 5	0CW2234P401//	BM	HR		B	Motor (MOT-NA4565B02)	ﾓｰﾀｰ
6	0CW2214P108//	AT	EZ		C	PF motor bracket	ｷｭｳｼﾓｰﾀｰﾌﾞﾗｹｯﾄ
7	0CW2214P316//	AS	EQ		C	Gear (GER-0.75-24H-0W)	ｷﾞﾔｰ
8	0CWE450000897	AC	DJ		C	Clamp (UAMS-05SN-W)	ｸﾗﾝﾌﾟ
9	0CW2214P341//	AP	EQ		C	Belt (BLT-S2M166-6)	ﾍﾞﾙﾄ
10	0CW2214P340//	AV	FG		C	Clock pulley (PLY-S2M-20)	ｸﾛｯｸﾌﾟｰﾘｰ
11	0CWE314000531	AN	EG		B	Photo interrupter (TLP1225(C5))	ﾌｫﾄｲﾝﾀﾗﾌﾟﾀｰ
12	0CW2214P109//	AE	DS		C	PF sensor bracket	ｷｭｳｼｾﾝｻｰﾌﾞﾗｹｯﾄ
13	0CW2214P319//	AP	EQ		B	Belt (BLT-S2M138-6)	ﾍﾞﾙﾄ
14	0CW2214P206//	AP	EQ		C	Shaft 2	ｼｬﾌﾄ2
15	0CW2214P205//	AK	EB		C	Shaft 1	ｼｬﾌﾄ1
16	0CW2214P019//	AP	EQ		C	Weight lever shaft	ｳｪｲﾄﾚﾊﾞｰｼﾞｸ
17	0CW2214P020//	AE	DJ		C	Lever	ｴﾝﾌﾟﾃｨｰﾚﾊﾞｰ
18	0CW2214P007//	AT	EZ		C	Guide	ｻﾊﾞｷｶﾞｲﾄﾞ
19	0CW2214P314//	AD	DJ		C	Shutter spring	ｼｬｯﾀｰﾊﾞﾈ
20	0CW2214P023B/	AE	DJ		C	Lever	ﾜﾆﾚﾊﾞｰ
21	0CW2214P036//	AE	DS		C	Shutter link	ｼｬｯﾀｰﾘﾝｸ
22	0CWE450000871	AB	DJ		C	Snap band (SG-110)	ｽﾅｯﾌﾟﾊﾞﾝﾄﾞ
23	0CW2214P021//	AE	DJ		C	Weight lever	ｳｪｲﾄﾚﾊﾞｰ
24	0CW2214P403//	AY	FQ		B	Solenoid (SOL-TDS-10SL-102)	ｿﾚﾉｲﾄﾞ
25	0CW2214P101//	AE	DJ		C	S solenoid bracket	Sｿﾚﾉｲﾄﾞﾌﾞﾗｹｯﾄ
26	0CW2214P313//	AD	DJ		C	Weight spring	ｳｪｲﾄﾊﾞﾈ
27	0CW2214P312//	AD	DJ		C	Resist spring	ﾚｼﾞﾊﾞﾈ
28	0CW2214P104F/	AR	EQ		C	A side plate F	AｿｸﾊﾞﾝF

3 給紙搬送部1 (Paper feeding transport section 1)

NO.	PARTS CODE	PRICE RANK		NEW MARK	PART RANK	DESCRIPTION	
		Ex.	Ja.				
29	0CW2214P022//	AE	DJ		C	Resist link	ﾚｼﾞﾘﾝｸ
30	0CW2214P302//	AX	FG		C	Resist pinch roller	ﾚｼﾞﾋﾟﾝﾁﾛｰﾗｰ
31	0CW2214P301//	BB	GD		C	Resist roller	ﾚｼﾞｽﾄﾛｰﾗｰ
32	0CW2214K216//	AH	DX		C	ASM-SOL harness	ASM-SOLﾊｰﾈｽ
33	0CW2214P200//	AZ	FQ		C	Shaft	ｻﾊﾞｷｼﾞｸ
34	0CW2214P339//	BA	FX		C	Roller	ｸｼﾊﾞﾛｰﾗｰ
35	0CW2214P201//	AV	FG		C	Pick up shaft	ﾋﾟｯｸｱｯﾌﾟｼｬﾌﾄ
36	0CW2214P300D/	AU	FG		C	Shutter	ｼｬｯﾀｰ
37	0CWE120000870	AM	EG		B	Microswitch (SS-5T)	ﾏｲｸﾛｽｲｯﾁ
38	0CW2214P317//	AS	EQ		C	Gear (GER-0.75-32H-0W)	ｷﾞﾔｰ
39	0CW2214P318//	AR	EQ		B	Belt (BLT-B100-S2M120)	ﾍﾞﾙﾄ
40	0CW2214P320//	AQ	EQ		B	Belt (BLT-B60-S2M248)	ﾍﾞﾙﾄ
41	0CW2214P031//	AF	DS		C	Pulley (PLY-S2M-24)	ﾌﾟｰﾘｰ
42	0CW2214K033//	AL	EB		C	Idler bracket ass'y	ｱｲﾄﾞﾗﾌﾞﾗｹｯﾄｶｼﾒｸﾐ
43	0CW2214P342//	AS	EQ		C	Gear (GER-0.75-H-0W)	ｷﾞﾔｰ
44	0CW2214P032//	AF	DS		C	Gear (GER-0.75-32H)	ｷﾞﾔｰ
45	0CW2214K027E/	AX	FG		C	A side plate R ass'y	AｿｸﾊﾞﾝRｶｼﾒｸﾐ
46	XRESP50-06000	AA	DD		C	E type ring	Eﾘﾝｸﾞ (ER050SKP)
47	0CW690381////	AE	DS		C	Bearing MF	ｼﾞｸｳｹMF
48	0CW319300////	AD	DJ		B	Bearing (8MM)	ｼﾞｸｳｹ 8MM
49	XRESP70-08000	AA	DD		C	E type ring	Eﾘﾝｸﾞ (ER070SKP)
50	0CWHP020120SC	AC	DJ		C	Pin (ϕ2-12)	ﾍｲｺｳﾋﾟﾝ
51	0CW1001P441//	AG	DX		C	Bolt (3×6)(BOT-SW-HW CAP)	ﾎﾞﾙﾄ
52	0CW2078P023B/	AC	DJ		C	Screw 1.4 (M3)	M3ﾀﾞﾝﾋﾞｽ 1.4
53	0CW2158P521B/	AE	DJ		C	Bearing 6	ｼﾞｸｳｹ-6
54	XRESP80-09000	AA	DD		C	E type ring	Eﾘﾝｸﾞ (ER080SKP)
55	0CW2166P034B/	AC	DJ		C	Clip-5	ｸﾘｯﾌﾟｰ5
56	0CW2214P471//	AQ	EQ		C	Semicircular roller SHP	ﾊﾝｹﾞﾂﾛｰﾗｰSHP
57	0CWHP020140SC	AC	DJ		C	Pin (ϕ2-14)	ﾍｲｺｳﾋﾟﾝ
58	0CW2158P003D/	AF	DS		C	Switch lever	SWﾚﾊﾞｰ
59	0CW338432////	AC	DD		B	Bearing 4	ｼﾞｸｳｹ 4
60	0CWHP020060SC	AC	DJ		C	Pin (ϕ2-6)	ﾍｲｺｳﾋﾟﾝ
61	XRESP30-05000	AA	DD		C	E type ring	Eﾘﾝｸﾞ (ER030SKP)
62	0CWSP030100FP	AC	DJ		C	Spring pin (ϕ3×10)	ｽﾌﾟﾘﾝｸﾞﾋﾟﾝ
63	0CW030060FZTP	AA	DD		C	Screw (3×6)	ITﾀｯﾌﾟﾀｲﾄﾈｼﾞ
65	0CW030080FPWP	AB	DJ		C	Screw (3×8)	6ｶｸｱﾅﾂｷﾄﾒﾈｼﾞ
66	0CW2198P003//	AH	DX		C	Pulley (PLY-S2M-56)	ﾌﾟｰﾘｰ
67	0CW030060FZiT	AA	DD		C	Screw (3×6)	ITﾈｼﾞ
68	0CW4016P167//	AC	DJ		C	Screw (SCR030050)	ﾈｼﾞ
69	0CW2158P377//	AB	DJ		C	Screw (3×4)	ﾋﾗﾈｼﾞ
70	0CW338422////	AB	DD		B	Bearing 6	ｼﾞｸｳｹ 6
71	0CW030080FZWS	AA	DD		C	Screw (3×8)	Wｾﾑｽﾈｼﾞ
72	0CW2214P469//	AE	DJ		C	PWR sheet 2	PWRﾏｲﾗｰ2
73	0CW2214P456B/	AG	DX		C	PWR sheet	PWRﾏｲﾗｰ
75	0CW2168P029//	AF	DS		C	Gear (GER-0.75-21H-L)	ｷﾞﾔｰ
76	0CW2214P491//	AH	DX		C	Curl sheet F-K	ｶｰﾙﾏｲﾗｰF-K
77	0CW040060FZBP	AB	DJ		C	Screw (4×6)	ﾊﾞｲﾝﾄﾞﾀｯﾌﾟﾀｲﾄﾈｼﾞ
78	0CW2168P030//	AG	DX		C	Pulley (PLY-S2M-50)	ﾌﾟｰﾘｰ
79	0CW2142P037//	AS	EQ		C	Pulley (PLY18 O/W G373)	ﾌﾟｰﾘｰ
80	0CW023140FBWS	AC	DJ		C	Screw (2.3×14)	Wｾﾑｽﾈｼﾞ
81	0CW030030FZiT	AB	DJ		C	Screw (3×3)	ITﾈｼﾞ
82	0CW2078P652//	AE	DS		C	Bearing 8	ｼﾞｸｳｹ8
83	0CW2088P034//	AK	EB		C	Stopper 6	ｽﾅｯﾌﾟ6
84	0CW2095P310//	AD	DJ		C	Stopper 8	ｼﾞｸﾄﾞﾒ8
85	0CW2214K101//	AL	EB		C	DF support plate ass'y	DFｼｼﾞｲﾀｶｼﾒｸﾐ
86	0CW2234P008//	AG	DX		C	Weight	Nｳｴｲﾄ
87	0CW2214P524//	AG	DS		C	Weight sheet	ｳｴｲﾄﾏｲﾗｰ
88	0CW2214P492//	AH	DX		C	Curl sheet R-K	ｶｰﾙﾏｲﾗｰR-K
89	0CW2129P188//	AD	DJ		C	Crip (CLIP 3)	KL-ｸﾘｯﾌﾟ
90	0CW2223P101//	AD	DJ		C	A earth spring	Aｱｰｽｲﾀﾊﾞﾈ
91	0CW2214P531//	AC	DJ		C	Spacer	SWｽﾍﾟｰｻｰ
92	0CW2234P301//	AF	DS		C	Lever spring	ｴﾝﾌﾟﾃｨｰﾚﾊﾞｰｽﾌﾟﾘﾝｸﾞ
93	0CW2214P528//	AC	DJ		C	MSW sheet	MSWﾏｲﾗｰ
94	0CWHW030FZM//	AA	DJ		C	Washer	ﾜｯｼｬ
95	0CW2198K239//	AG	DX		C	ASM earth wire 2	ASMｱｰｽｾﾝ2
96	0CW030030FNiT	AB	DJ		C	Screw (3×3)	ﾋﾞｽ
97	XRESP40-06000	AA	DD		C	E type ring	Eﾘﾝｸﾞ (ER040SKP)

3 給紙搬送部1 (Paper feeding transport section 1)



4 給紙搬送部2 (Paper feeding transport section 2)

NO.	PARTS CODE	PRICE RANK		NEW MARK	PART RANK	DESCRIPTION	
		Ex.	Ja.				
1	0CW2214P102//	AE	DJ		C	Tray connector bracket	ﾄﾚｲｺﾈｸﾀﾌﾞﾗｹｯﾄ
2	0CW2214K201//	AP	EQ		C	ASM-TR2 harness	ASM-TR2ﾊｰﾈｽ
3	0CW2214P343//	AE	DJ		C	Pick up sheet	ﾋﾟｯｸｱｯﾌﾟﾏｲﾗｰ
4	0CWE450000896	AC	DJ		C	Clamp (UAMS-02WH-2)	ｸﾗﾝﾌﾟ
5	0CW2214P061//	AY	FQ		C	A tray guide	Aﾄﾚｲｶﾞｲﾄﾞ(C)
6	0CWE314000528	AL	EB		B	Photo interrupter (TLP1240(C5))	ﾌｫﾄｲﾝﾀﾗﾌﾟﾀｰ
7	0CW2214P132D/	AM	EG		C	Stay	ｻﾎﾟｰﾄｽﾃｲ
8	0CW2214P131//	AG	DX		C	Bracket	ｻﾎﾟｰﾄｲﾀﾌﾞﾗｹｯﾄ
9	0CW2214P155//	AG	DX		C	Plate 2	ﾏｴｻﾎﾟｰﾄｲﾀ 2
10	0CW2214P104F/	AR	EQ		C	A side plate F	AｿｸﾊﾞﾝF
11	0CWE450000433	AB	DD		C	Edge saddle 1 (EDS-1)	ｴｯｼﾞｻﾄﾞﾙ1
12	0CW2214K224//	AS	EQ		E	PBA-sensor PWB	PBA-ｾﾝｻｰｷﾊﾞﾝ
13	0CW2214P134//	AF	DS		C	Resist sensor bracket	ﾚｼﾞｾﾝｻｰﾌﾞﾗｹｯﾄ
14	0CW2214K214//	AG	DX		C	ASM-earth wire W	ASM-ｱｰｽｾﾝW
15	0CW2214K032//	AK	EB		C	Sensor bracket ass'y	ﾊﾊﾟｾﾝｻｰﾌﾞﾗｹｯﾄｶｼﾒｸﾐ
16	0CW2214P311//	AF	DS		C	Sensor spring	ﾊﾊﾟｾﾝｻｰﾊﾞﾈ
17	0CW2214P030//	AE	DJ		C	Sensor lever	ﾊﾊﾟｾﾝｻｰﾚﾊﾞｰ
18	0CW2214P009//	AX	FG		C	U-turn guide	Uﾀｰﾝｶﾞｲﾄﾞ
19	0CW2214P307//	AD	DJ		C	Seal	ﾐﾗｰｼｰﾙﾚｼﾞ
20	0CW2214P067//	AU	FG		C	Resist guide	ﾚｼﾞｶﾞｲﾄﾞ(C)
21	0CW2214P062//	BA	FX		C	Paper feeding cover	ｷｭｳｼｶﾊﾞｰ(C)
22	0CW2214P303//	AD	DJ		C	Screw	M3ﾀﾞﾝﾋﾞｽ3.3
23	0CW2214P035C/	AF	DS		C	Fixing plate	ｻﾎﾟｰﾄｵｻｴ
24	0CW2214P344//	AE	DJ		C	Sheet	ｻﾎﾟｰﾄﾆｯﾌﾟﾏｲﾗｰ
25	0CW2214P306//	AV	FG		B	A discharge brush	Aｼﾞｮﾃﾞﾝﾌﾞﾗｼ
26	0CW2214P063//	AV	FG		C	Resist guide	ﾚｼﾞｺﾞｶﾞｲﾄﾞ(C)
27	0CW2214K027E/	AX	FG		C	A side plate R ass'y	AｿｸﾊﾞﾝRｶｼﾒｸﾐ
28	0CWE450000897	AC	DJ		C	Clamp (UAMS-05SN-W)	ｸﾗﾝﾌﾟ
29	0CW2214P103//	AD	DJ		C	MSW cover	MSWｶﾊﾞｰ
30	0CWE450000871	AB	DJ		C	Snap band (SG-110)	ｽﾅｯﾌﾟﾊﾞﾝﾄﾞ
31	0CW2214P406//	AD	DJ		C	SP tube 2	SPﾁｭｰﾌﾞ2
32	0CW2214K207//	AM	EG		C	ASM-sensor 2 harness	ASM-ｾﾝｻｰ2ﾊｰﾈｽ
33	0CW030080FZBB	AB	DJ		C	Screw (3×8)	Bﾀｲﾄﾈｼﾞ
34	0CW030060FZBi	AA	DD		C	Screw (3×6)	ﾊﾞｲﾝﾄﾞﾈｼﾞ
35	0CW2199P368//	AD	DJ		C	Stopper cushion	ｽﾄｯﾊﾟｰｸｯｼｮﾝ
36	0CW2158P377//	AB	DJ		C	Screw (3×4)	ﾋﾗﾈｼﾞ
37	0CW030060FZBP	AA	DD		C	Screw (3×6)	ﾊﾞｲﾝﾄﾞﾀｯﾌﾟﾀｲﾄﾈｼﾞ
38	0CW030040FZWS	AA	DD		C	Screw (3×4)	Wｾﾑｽﾈｼﾞ
39	0CW2078P023B/	AC	DJ		C	Screw 1.4 (M3)	M3ﾀﾞﾝﾋﾞｽ 1.4
40	0CW030060FZTP	AA	DD		C	Screw (3×6)	ITﾀｯﾌﾟﾀｲﾄﾈｼﾞ
41	0CW030040FZBi	AA	DD		C	Screw (3×4)	ﾊﾞｲﾝﾄﾞﾈｼﾞ
42	0CW030100FZBi	AA	DD		C	Screw (3×10)	ﾊﾞｲﾝﾄﾞﾈｼﾞ
43	0CW030060FNBi	AA	DJ		C	Screw (3×6)	ﾊﾞｲﾝﾄﾞﾈｼﾞ
44	0CW2129P188//	AD	DJ		C	Crip (CLIP 3)	KL-ｸﾘｯﾌﾟ
45	0CW2198P302//	AD	DJ		C	Mirror seal	ﾐﾗｰｼｰﾙ
46	0CW2078P086B/	AB	DD		C	Screw 2.2 (M3)	M3ﾀﾞﾝﾋﾞｽ 2.2
47	0CW030040FZiT	AA	DD		C	Screw (3×4)	ITﾈｼﾞ
48	0CW4016P167//	AC	DJ		C	Screw (SCR030050)	ﾈｼﾞ
49	XRESP40-06000	AA	DD		C	E type ring	Eﾘﾝｸﾞ(ER040SKP)
54	0CW2214P477//	AH	DX		C	Front plate rubber	ﾏｴｻﾎﾟｰｷｺﾞﾑ
57	0CW2214P455//	AE	DS		C	Lock plate spring	ﾛｯｸｲﾀﾊﾞﾈ
58	0CW2214P521//	AF	DS		C	Resist guide sheet	ﾚｼﾞｶﾞｲﾄﾞﾏｲﾗｰ
59	0CW2214P458//	AG	DX		C	U turn guide sheet	Uﾀｰﾝｶﾞｲﾄﾞﾏｲﾗｰ
60	0CW2214P154D/	AH	DX		C	Spring	ｻﾎﾟｰｷｶｲｼﾞｮﾊﾞﾈ
61	0CWE450000574	AC	DJ		C	Wire clamp (UAMS-05S-2)	ﾜｲﾔｰｸﾗﾝﾌﾟ
62	0CW2214P144//	AF	DS		C	EMP sensor bracket	EMPｾﾝｻｰﾌﾞﾗｹｯﾄ
63	0CW2234P322//	AH	DX		C	Rubber 1	ｻﾎﾟｰｷｳﾚﾀﾝｺﾞﾑ1
66	0CW2214P494//	AD	DJ		C	Plate 1 sheet (Japan only)	ｻﾎﾟｰｷﾌﾟﾚｰﾄ1-Kﾏｲﾗｰ
68	0CW2223P102//	AH	DX		C	Plate 1	ｻﾎﾟｰｷﾌﾟﾚｰﾄ1
69	0CW2214P485//	AD	DJ		C	Spring	ｻﾎﾟｰｷｶｲｼﾞｮﾊﾞﾈ
70	0CW2078P119B/	AB	DD		C	Screw 3.2 (M3)	M3ﾀﾞﾝﾋﾞｽ 3.2
72	0CW2205P050//	AD	DJ		C	Resist collar	ﾚｼﾞｽﾄｺﾛ
73	0CW2205P153//	AF	DS		C	Separator stay	ﾌﾞﾝﾘｽﾃｲ
78	0CW2205P052//	AE	DJ		C	Slide bearing	ｽﾗｲﾄﾞｼﾞｸｳｹ
79	0CW2231K064//	AY	FQ		C	Separator roller DX	ﾌﾞﾝﾘﾛｰﾗｰ DX
80	0CW2205P051//	AE	DJ		B	Bearing (ϕ5)	ｼﾞｸｳｹ5
81	0CW2214P391//	AG	DS		C	Separator pressure spring F	ﾌﾞﾝﾘｱﾂｾﾂﾊﾞﾈF
82	0CW2205P035//	AF	DS		C	Separator roller holder	ﾌﾞﾝﾘﾛｰﾗｰﾎﾙﾀﾞｰ
83	0CW2214P392//	AG	DS		C	Separator pressure spring R	ﾌﾞﾝﾘｱﾂｾﾂﾊﾞﾈR
84	0CW020050FZSA	AB	DJ		C	Screw (2×5)	ｻﾗﾈｼﾞ
85	0CW2205P152//	AK	EB		C	Separator bracket	ﾌﾞﾝﾘﾌﾞﾗｹｯﾄ
86	0CW2214P376//	AH	DX		C	Resist sheet	ﾚｼﾞｺﾏｲﾗｰ
87	0CW2214P493//	AG	DS		C	Stay edge sheet	ｻﾎﾟｰｷｽﾃｲｴｯｼﾞﾏｲﾗｰ
89	0CW2214P454//	AD	DJ		C	Sheet	ｱﾂｶﾞﾐﾏｲﾗｰ
90	0CW2158P348A/	AD	DJ		C	Cushion	ﾎﾞｳｵﾝｻﾞｲ
501	0CW2214K116//	AH	DX		E	Sheet ass'y (Except Japan)	ｻﾎﾟｰﾄ1ﾏｲﾗｰｸﾐ
502	0CW2234K181//	AX	FG	N	E	Separator shaft ass'y CJP (Japan only)	ﾌﾞﾝﾘｼﾞｸｸﾐCJP
	0CW2234K176//	AU	FG	N	E	Separator shaft ass'y IS (Except Japan)	ﾌﾞﾝﾘｼﾞｸｸﾐIS

4 給紙搬送部2 (Paper feeding transport section 2)



5 反転搬送部 (Reversion transport section)

NO.	PARTS CODE	PRICE RANK		NEW MARK	PART RANK	DESCRIPTION	
		Ex.	Ja.				
1	0CW2214P113//	AF	DS		C	Flapper solenoid bracket	ﾌﾗｯﾊﾟｰSOLﾌﾞﾗｹｯﾄ
2	0CWE450000574	AC	DJ		C	Wire clamp (UAMS-05S-2)	ﾜｲﾔｰｸﾗﾝﾌﾟ
3	0CW2214P402//	AU	FG		B	Solenoid (SOL-TDS-06A-4013)	ｿﾚﾉｲﾄﾞ
4	0CW319300////	AD	DJ		B	Bearing (8MM)	ｼﾞｸｳｹ 8MM
5	0CW2214K004//	AR	EQ		C	Turn over side plate F ass'y	ﾊﾝﾃﾝｿｸﾊﾞﾝFｶｼﾒｸﾐ
6	0CW2214P349//	AN	EQ		C	Pulley (PLY-S2M-17-0W)	ﾌﾟｰﾘｰ
7	0CWE450000871	AB	DJ		C	Snap band (SG-110)	ｽﾅｯﾌﾟﾊﾞﾝﾄﾞ
8	0CW2214P348//	AX	FG		C	Pulley (PLY-S2M-28-31)	ﾌﾟｰﾘｰ
9	0CWE450000433	AB	DD		C	Edge saddle 1 (EDS-1)	ｴｯｼﾞｻﾄﾞﾙ1
10	0CWE450000896	AC	DJ		C	Clamp (UAMS-02WH-2)	ｸﾗﾝﾌﾟ
11	0CW2214P120//	AQ	EQ		C	Turn over motor bracket	ﾊﾝﾃﾝﾓｰﾀｰﾌﾞﾗｹｯﾄ
12	0CW2234P400//	BK	HC		B	Motor (MOT-KH56JM2B013)	ﾓｰﾀｰ
13	0CW2214P323//	AV	FG		C	R delivery roller	Rﾊｲｼﾛｰﾗ
14	0CW2214K211//	AL	EB		C	ASM-RU harness	ASM-RUﾊｰﾈｽ
15	0CW2214P377C/	AS	EZ		B	Delivery discharge brush	ﾊｲｼｼﾞｮﾃﾞﾝﾌﾞﾗｼ
16	0CW2214P143C/	AP	EQ		C	R guide 2	Rｶﾞｲﾄﾞ2
17	0CW2214P347//	AD	DJ		C	Flapper rubber	ﾌﾗｯﾊﾟｰｺﾞﾑ
18	0CW2214K002//	AW	FG		C	Turn over side plate R ass'y	ﾊﾝﾃﾝｿｸﾊﾞﾝRｶｼﾒｸﾐ
19	0CWE120000870	AM	EG		B	Microswitch (SS-5T)	ﾏｲｸﾛｽｲｯﾁ
20	0CW2214P332//	AV	FG		C	Flapper	ﾌﾗｯﾊﾟｰ
21	0CW2214P331//	BD	GN		C	Turn over roller	ﾊﾝﾃﾝﾛｰﾗｰ
22	0CW2214P381//	AD	DJ		C	H sensor upper sheet	Hｾﾝｻｰｳｴﾏｲﾗｰ
24	0CW2214K222//	AS	EQ		E	PBA sensor PWB	PBA-ﾊﾝﾃﾝｾﾝｻｰｷﾊﾞﾝ
25	0CW2214P012//	AR	EQ		C	R lower guide	Rｼﾀｶﾞｲﾄﾞ
26	0CW2214P064//	AX	FG		C	Turn over guide cover	ﾊﾝﾃﾝｶﾞｲﾄﾞｶﾊﾞｰ(C)
27	0CW2214P209//	AE	DJ		C	U turn over collar shaft	Uﾊﾝﾃﾝｺﾛｼﾞｸ
28	0CW2214P033//	AE	DJ		C	Turn over collar	ﾊﾝﾃﾝｺﾛ
29	0CW2214P130//	AP	EQ		C	H reinforce plate	Hﾎｷｮｳﾌﾟﾚｰﾄ
30	0CW2214P011//	AQ	EQ		C	Lower guide	ｼﾀｶﾞｲﾄﾞ
31	0CW2214P124//	AE	DJ		C	Turn over collar plate spring	ﾊﾝﾃﾝｺﾛｲﾀﾊﾞﾈ
32	0CW2214P208//	AD	DJ		C	Turn over collar shaft	ﾊﾝﾃﾝｺﾛｼﾞｸ
33	0CW2214P352//	AD	DJ		C	Turn over seal	ﾊﾝﾃﾝﾐﾗｰｼｰﾙ
34	0CW030060FZBi	AA	DD		C	Screw (3×6)	ﾊﾞｲﾝﾄﾞﾈｼﾞ
35	0CW030060FZSW	AA	DD		C	Screw (3×6)	Wｾﾑｽﾈｼﾞ
36	XRESP70-08000	AA	DD		C	E type ring	Eﾘﾝｸﾞ(ER070SKP)
37	0CW2214P328//	AS	EQ		C	Pulley (PLY-S2M-30-0W)	ﾌﾟｰﾘｰ
38	0CW2078P086B/	AB	DD		C	Screw 2.2 (M3)	M3ﾀﾞﾝﾋﾞｽ 2.2
39	0CW2158P003D/	AF	DS		C	Switch lever	SWﾚﾊﾞｰ
40	0CW030060FZTP	AA	DD		C	Screw (3×6)	ITﾀｯﾌﾟﾀｲﾄﾈｼﾞ
41	0CW2158P009A/	AD	DJ		C	R flapper link	Rﾌﾗｯﾊﾟｰﾘﾝｸ
42	0CW2158P005A/	AD	DJ		C	Solenoid stopper pin	SOLｽﾄｯﾊﾟｰﾋﾟﾝ
43	XRESP50-06000	AA	DD		C	E type ring	Eﾘﾝｸﾞ(ER050SKP)
44	0CW2147P033//	AD	DJ		C	R flapper link 1	Rﾌﾗｯﾊﾟｰﾘﾝｸ 1
45	0CWHP020100SC	AC	DJ		C	Pin (ϕ2-10)	ﾍｲｺｳﾋﾟﾝ
46	0CW2158P521B/	AE	DJ		C	Bearing 6	ｼﾞｸｳｹ-6
47	0CW2094P090A/	AH	DX		B	Timing belt (44-40S2M88)	ﾀｲﾐﾝｸﾞﾍﾞﾙﾄ
48	0CW040080FZBi	AA	DD		C	Screw (4×8)	ﾊﾞｲﾝﾄﾞﾈｼﾞ
49	0CW4016P167//	AC	DJ		C	Screw (SCR030050)	ﾈｼﾞ
50	0CW030060FZBP	AA	DD		C	Screw (3×6)	ﾊﾞｲﾝﾄﾞﾀｯﾌﾟﾀｲﾄﾈｼﾞ
51	0CW2214P529//	AC	DJ		C	Screw	M3ﾀﾞﾝﾋﾞｽ2.4
52	0CW030040FZBi	AA	DD		C	Screw (3×4)	ﾊﾞｲﾝﾄﾞﾈｼﾞ
53	0CW2214P455//	AE	DS		C	Lock plate spring	ﾛｯｸｲﾀﾊﾞﾈ
54	0CW2107P032//	AN	EG		C	Belt (S2M-56-4)	ﾍﾞﾙﾄ
55	0CW040100FPWP	AC	DJ		C	Screw (4×10)	6ｶｸﾒｯｷﾄﾒﾈｼﾞ
56	0CW2221P336//	AU	EZ		C	Protect rubber	ﾎﾞｳｼﾝｺﾞﾑ
57	0CW2214P464//	AE	DJ		C	R lower soft sheet	Rｼﾀｿﾌﾄﾏｲﾗｰ
58	0CW2214P459//	AD	DJ		C	R lower guide sheet F	RｼﾀｶﾞｲﾄﾞﾏｲﾗｰF
59	0CW030080FZBB	AB	DJ		C	Screw (3×8)	Bﾀｲﾄﾈｼﾞ
60	0CW2214P460//	AD	DJ		C	R lower guide sheet R	RｼﾀｶﾞｲﾄﾞﾏｲﾗｰR
61	0CW2214P466//	AG	DX		C	R lower sheet	Rｼﾀﾘﾌﾞﾏｲﾗｰ
62	0CW338412////	AE	DS		B	Bearing 8	ｼﾞｸｳｹ 8
63	0CW023120FBWS	AB	DJ		C	Screw (2.3×12)	Wｾﾑｽﾈｼﾞ
64	0CW2214P472//	AP	EQ		C	Turn over sheet	ﾊﾝﾃﾝﾏｲﾗｰ
65	0CW2214P146//	AD	DJ		C	Belt flange	ﾍﾞﾙﾄﾌﾗﾝｼﾞ
66	0CW2214P103//	AD	DJ		C	MSW cover	MSWｶﾊﾞｰ
67	0CW2214P046//	AE	DS		C	Turn over sensor cover	ﾊﾝﾃﾝｾﾝｻｰｶﾊﾞｰ
68	0CW2214P383//	AE	DJ		C	H sensor lower sheet	Hｾﾝｻｰｼﾀﾏｲﾗｰ
69	0CW2214P335//	AD	DJ		C	R flapper spring	Rﾌﾗｯﾊﾟｰﾊﾞﾈ
70	0CW2214K210//	AT	EZ		C	ASM-deive R harness	ASM-ﾄﾞﾗｲﾌﾞRﾊｰﾈｽ
71	0CW2214P387//	AE	DS		C	Turn over guide sheet	ﾊﾝﾃﾝｶﾞｲﾄﾞﾏｲﾗｰ
72	0CW2214P465//	AM	EG		C	H belt guide sheet	Hﾍﾞﾙﾄｶﾞｲﾄﾞﾏｲﾗｰ
73	0CW2234P335//	AG	DS	N	C	R Guide 2 sheet F	Rｶﾞｲﾄﾞ2ﾏｲﾗｰF
74	0CW2234P336//	AG	DS	N	C	R Guide 2 sheet R	Rｶﾞｲﾄﾞ2ﾏｲﾗｰR
75	0CW2198K239//	AG	DX		C	ASM earth wire 2	ASMｱｰｽｾﾝ2

5 反転搬送部（Reversion transport section)



7 給紙ﾄﾚｲ部 (Paper feedig tray section)

NO.	PARTS CODE	PRICE RANK Ex.	PRICE RANK Ja.	NEW MARK	PART RANK	DESCRIPTION	
1	0CW2214P065//	AZ	FX		C	Tray cover	ﾄﾚｲｶﾊﾞｰ(C)
2	0CW2214P005//	AG	DS		C	Slide holder R	ｽﾗｲﾄﾞﾎﾙﾀﾞｰR
3	0CW2214P004//	AF	DS		C	Tray rack	ﾄﾚｲﾗｯｸ
4	0CW2214P039//	AG	DS		C	Slide holder F	ｽﾗｲﾄﾞﾎﾙﾀﾞｰF
5	0CW2223K214//	AX	FG		C	ARM-VR harness	ASM-VRﾊｰﾈｽ
6	0CW2214P128//	AK	DX		C	Slide switch bracket	ｽﾗｲﾄﾞSWﾌﾞﾗｹｯﾄ
7	0CW2234K202//	AT	EZ		C	ASM-TRAY 2234 harness (Inch series･･**Except U.S.A.,CANADA**)	ASM-TRAY2234ﾊｰﾈｽ
	0CW2214K202E/	AS	EQ		C	ASM-TRAY harness (Other countries)	ASM-TRAYﾊｰﾈｽ
8	0CWE450000368	AD	DJ		C	Clamp (T18MR)	ｸﾗﾝﾌﾟ
9	0CWE314000120	AM	EG		B	Proto interrupter (GP1A25LC)(Except Japan,Europe)	ﾌｫﾄｲﾝﾀﾗﾌﾟﾀｰ
10	0CWE314000120	AM	EG		B	Photo interrupter (GP1A25LC)	ﾌｫﾄｲﾝﾀﾗﾌﾟﾀｰ
11	0CW2214P066//	BA	FX		D	Original tray	ｹﾞﾝｺｳﾄﾚｲ(C)
12	0CW2214P129//	AF	DS		C	Tray guide plate spring	ﾄﾚｲｶﾞｲﾄﾞｲﾀﾊﾞﾈ
13	0CW2214P059//	AK	DX		C	Tray guide R	ﾄﾚｲｶﾞｲﾄﾞR(C)
14	0CW2214P060//	AK	DX		C	Tray guide F	ﾄﾚｲｶﾞｲﾄﾞF(C)
15	0CW030080FZBB	AB	DJ		C	Screw (3×8)	Bﾀｲﾄﾈｼﾞ
16	0CW2199P117//	AE	DS		C	Tray plate spring	ﾄﾚｲｲﾀﾊﾞﾈ
17	0CW2142P180//	AE	DS		C	Tray gear 22	ﾄﾚｲ ｷﾞﾔ-22
18	0CW030060FNBi	AA	DJ		C	Screw (3×6)	ﾊﾞｲﾝﾄﾞﾈｼﾞ
19	0CW2214P070//	AH	DX		C	Tray sensor lever	ﾄﾚｲ-ｾﾝｻｰﾚﾊﾞｰ(C)
20	0CW030100FBBB	AB	DJ		C	Screw (3×10)	Bﾀｲﾄﾈｼﾞ
21	0CWE450000067	AC	DJ		C	Wire clamp (NK-2N)	ﾜｲﾔｰｸﾗﾝﾌﾟ
22	0CW2214P541//	AD	DJ		C	Indication label	ｼｼﾞｾﾝﾗﾍﾞﾙC
23	0CW2214P542//	AR	EQ		D	Tray scale (AB series･･**For Europe**)	ﾄﾚｲｽｹｰﾙ(C-BG,BK)
	0CW2214P544//	AN	EG		D	Tray scale (inch series)	ﾄﾚｲｽｹｰﾙ(C-INT)
	0CW2214P545//	AR	EQ		D	Tray scale (Japan only)	ﾄﾚｲｽｹｰﾙ(C-JP)
	0CW2214P546//	AV	FG		D	Tray scale (AB series･･**Except Europe**)	ﾄﾚｲｽｹｰﾙ(C-BE)
24	0CW2214P070//	AH	DX		C	Tray sensor lever (Except Japan,Europe)	ﾄﾚｲ-ｾﾝｻｰﾚﾊﾞｰ(C)
25	0CWE314000531	AN	EG		B	Photo interrupter (TLP1225(C5))(Inch series･･**Except U.S.A.,CANADA**)ﾌｫﾄｲﾝﾀﾗﾌﾟﾀｰ
26	0CW4054P074B/	AF	DS		C	R-T sensor bracket (Inch series･･**Except U.S.A.,CANADA**)	R-Tｾﾝｻｰﾌﾞﾗｹｯﾄ
27	0CW2235P039//	AG	DX		C	Tray sensor lever (Inch series･･**Except U.S.A.,CANADA**)	ﾄﾚｲ-ｾﾝｻｰﾚﾊﾞｰ
28	0CW030080FZBB	AB	DJ		C	Screw (3×8)(Inch series･･**Except U.S.A.,CANADA**)	Bﾀｲﾄﾈｼﾞ
29	0CWE450000368	AD	DJ		C	Clamp (T18MR)(Inch series･･**Except U.S.A.,CANADA**)	ｸﾗﾝﾌﾟ
30	0CW030100FBBB	AB	DJ		C	Screw (3×10)(Inch series･･**Except U.S.A.,CANADA**)	Bﾀｲﾄﾈｼﾞ
31	0CWE450000005	AA	DD		C	Tight band (SKB-1N)(Japan,Europe)	ﾊﾞﾝﾄﾞ

7 給紙ﾄﾚｲ部 (Paper feedig tray section)



8 梱包材＆付属品 (Packing material & Accessories)

NO.	PARTS CODE	PRICE RANK		NEW MARK	PART RANK	DESCRIPTION	
		Ex.	Ja.				
1	PCOVP0911FCZ1	AC	DJ		D	Upper exterior rear cover R	ｳｴｷｬﾋﾞｱﾄｶﾊﾞｰR
2	PCOVP0941FCZ1	AC	DJ		D	Upper exterior rear cover L	ｳｴｷｬﾋﾞｱﾄｶﾊﾞｰL
3	0CW2214K113//	AD	DJ		C	Screw ass'y (4×8)	ﾊﾞｲﾝﾄﾞﾈｼﾞｸﾐ
4	XBTSC50P16000	AA	DD		C	Screw (5×16)	ﾊﾞｲﾝﾄﾞﾈｼﾞ(050120FNBI)
5	LX-BZ0776FCZZ	AG	DS		C	Screw	ﾀﾞﾝﾈｼﾞR(2158P328)
6	0CW2214K058//	BB	GD		D	Packing add ass'y	ｺﾝﾎﾟｳﾊﾟｯﾄｸﾐ
7	0CW2214P470//	AH	DX		D	Fixing pad	ｵｻｴﾊﾟｯﾄ
8	0CW2234P334//	AQ	EQ	N	D	Card (Japanese) (Japan only)	ｾｯﾁﾃｼﾞｭﾝｼｮ(C-ｺｸﾅｲ)
10	0CW2214P384//	AP	EQ		D	Tray pad	ﾄﾚｲﾊﾟｯﾄ
12	0CW2234P331//	BC	GD	N	D	Packing case-TN (Japan only)	ｺﾝﾎﾟｳﾊﾞｺ-(CJP)TN
	0CW2234P330//	BC	GJ	N	D	Packing case (Japan only)	ｺﾝﾎﾟｳﾊﾞｺ(CJP)
13	0CW2214P358//	AB	DJ		D	Vinyl bag 1 (500×550mm)	ﾎｰﾙｽﾙｰﾌﾞｸﾛ1
14	0CW2158P380//	AE	DJ		D	Harness packing cushion S (150×120mm)	ﾊｰﾈｽﾊﾟｯｷﾝS
15	0CW2148P093A/	AE	DS		D	Vinyl bag (900×800mm)	ﾋﾞﾆｰﾙﾌﾞｸﾛ ｱﾅｱｷ(062)
16	0CW616371////	AA	DJ		D	Vinyl bag C (80×120mm)	ﾋﾞﾆｰﾙﾌﾞｸﾛC
17	0CW2111P021//	AC	DJ		D	Vinyl bag A (230×340mm)	ﾎｰﾙｽﾙｰﾌﾞｸﾛA

8 梱包材＆付属品 (Packing material & Accessories)



FCP03421

9 PBA-ｺﾝﾄﾛｰﾙ基板 (PBA-Control PWB)

NO.	PARTS CODE	PRICE RANK		NEW MARK	PART RANK	DESCRIPTION	
		Ex.	Ja.				
1	0CWE73423M106	AC	DJ		C	Capacitor (CESEM1E100-F)	[C10,C11]ｺﾝﾃﾞﾝｻ
2	0CWE73497Z104	AA	DJ		C	Capacitor (GRM39F104Z25PT)	[C35~C39,C42~C44,C46,C47,C49,C50]ｺﾝﾃﾞﾝｻ
3	0CWE73268J101	AF	DS		C	Capacitor (GRM40CH101J50PT)	[C32,C33]ｺﾝﾃﾞﾝｻ
4	0CWE73303Z105	AD	DJ		C	Capacitor (GRM40F105Z16PT)	[C41,C45,C48,C51,C52,C59~C62]ｺﾝﾃﾞﾝｻ
5	0CWE73431M107	AF	DS		C	Capacitor (CEEFM1H101M5-F)	[C53,C54]ｺﾝﾃﾞﾝｻ
6	0CWE73423M476	AC	DJ		C	Capacitor (CESEM1C470M-F)	[C55]ｺﾝﾃﾞﾝｻ
7	0CWE73423M475	AC	DJ		C	Capacitor (CESEM1H4R7-F)	[C57]ｺﾝﾃﾞﾝｻ
8	0CWE73303Z224	AC	DJ		C	Capacitor (GRM40F224Z50PT)	[C56]ｺﾝﾃﾞﾝｻ
9	0CWE74212WE06	AE	DJ		C	Connector (DF1B-6P-25DSA)	[CN4]ｺﾈｸﾀ
10	0CWE74212WE08	AE	DJ		C	Connector (DF1B-8P-2.5DSA)	[CN7]ｺﾈｸﾀ
11	0CWE74212WE09	AE	DS		C	Connector (DF1B-9P-25DSA)	[CN5]ｺﾈｸﾀ
12	0CWE323000343	AD	DJ		B	IC (M93C46MN6)	[IC3]IC
13	0CWE321000645	BB	GD		B	IC (STK6713BMK4)	[IC8]IC
14	0CWE321000644	AZ	FQ		B	IC (STK6712BMK4)	[IC12]IC
15	0CWE312001362	AC	DJ		B	Transistor (FN1L3M)	[Q12]ﾄﾗﾝｼﾞｽﾀｰ
16	0CWE312001293	AR	EQ		B	Transistor (2SJ265)	[Q13]ﾄﾗﾝｼﾞｽﾀｰ
17	0CWE312001368	AK	DX		B	FET (2SK1282-Z)	[Q15]ﾄﾗﾝｼﾞｽﾀｰ
18	0CWE312001310	AC	DJ		B	Transistor (FA1L3M)	[Q17]ﾄﾗﾝｼﾞｽﾀｰ
19	0CWE70162J101	AA	DJ		C	Resistor (CRG8SG101J)	[R93,R94]ﾃｲｺｳ
20	0CWE70162J181	AA	DJ		C	Resistor (CRG8SG181J)	[R100,R101]ﾃｲｺｳ
21	0CWE70188J203	AA	DJ		C	Resistor (CRG10G203J)	[R105]ﾃｲｺｳ
22	0CWE70162J202	AA	DJ		C	Resistor (CRG8SG202J)	[R106]ﾃｲｺｳ

9 PBA-ｺﾝﾄﾛｰﾙ基板 (PBA-Control PWB)

NO.	PARTS CODE	PRICE RANK Ex.	PRICE RANK Ja.	NEW MARK	PART RANK	DESCRIPTION
23	0CWE70162J100	AA	DJ		C	Resistor (CRG8SG100J) [R118]ﾃｲｺｳ
24	0CWE70188J154	AA	DJ		C	Resistor (CRG10G154J) [R47]ﾃｲｺｳ
25	0CWE70213JR39	AC	DJ		C	Resistor (RSSX1U039ΩJ) [R97~R99]ﾃｲｺｳ
26	0CWE70188F751	AA	DJ		C	Resistor (CRG10G751F) [R67]ﾃｲｺｳ
27	0CWE70162J472	AA	DJ		C	Resistor (CRG8SG472J) [R25]ﾃｲｺｳ
28	0CWE70205J222	AC	DJ		C	Resistor (CRG2G222J) [R107]ﾃｲｺｳ
29	0CWE70188F243	AA	DJ		C	Resistor (CRG10G243F) [R39]ﾃｲｺｳ
30	0CWE70188F683	AA	DJ		C	Resistor (CRG10G683F) [R112,R113]ﾃｲｺｳ
31	0CWE70188F912	AA	DJ		C	Resistor (CRG10G912F) [R114]ﾃｲｺｳ
32	0CWE70188F153	AA	DJ		C	Resistor (CRG10G153F) [R116]ﾃｲｺｳ
33	0CWE420001011	AC	DJ		C	Test pin (LC-3-SBK) [TP2]ﾃｽﾄﾋﾟﾝ
34	0CWE76008H160	AD	DJ		B	Zener diode (RD16MB2) [ZD3]ﾂｪﾅｰﾀﾞｲｵｰﾄﾞ
35	0CWE76008G180	AD	DJ		B	Zener diode (RD18MB1) [ZD5,ZD6,ZD7]ﾂｪﾅｰﾀﾞｲｵｰﾄﾞ
36	0CWE73425M107	AD	DJ		C	Capacitor (CEDSM1H101M-F) [C1]ｺﾝﾃﾞﾝｻ
37	0CWE73495K102	AB	DJ		C	Capacitor (GRM39B102K50PT) [C2~C7]ｺﾝﾃﾞﾝｻ
38	0CWE73303Z334	AC	DJ		C	Capacitor (GRM40F344Z25PT) [C9]ｺﾝﾃﾞﾝｻ
39	0CWE73495K103	AB	DJ		C	Capacitor (GRM39B103K50PT) [C12,C13,C16~C18,C21~C23]ｺﾝﾃﾞﾝｻ
41	0CWE73303Z104	AB	DJ		C	Capacitor (GRM40F104Z25PT) [C14,C15,C19,C20,C25,C26,C28~C30]ｺﾝﾃﾞﾝｻ
42	0CWE73425M476	AC	DJ		C	Capacitor (CEDSM1H470M-F) [C31,C40]ｺﾝﾃﾞﾝｻ
43	0CWE73423M105	AC	DJ		C	Capacitor (DESEM1H010-F) [C34]ｺﾝﾃﾞﾝｻ
44	0CWE74299BK06	AB	DD		C	Connector (DF3-6P-2DSA) [CN9]ｺﾈｸﾀ
46	0CWE74071WE04	AC	DJ		C	Connector (B4P-VH)(4pin) [CN6]ｺﾈｸﾀ
50	0CWE311000978	AD	DJ		B	Diode (SB02-03Q) [D1,D3,D4]ﾀﾞｲｵｰﾄﾞ
51	0CWE311000977	AB	DD		B	Diode (DSA010) [D6]ﾀﾞｲｵｰﾄﾞ
52	0CWE311001020	AE	DS		B	Diode (SS14) [D7,D8]ﾀﾞｲｵｰﾄﾞ
53	0CWE311001019	AD	DJ		B	Diode (S1G-G11) [D2,D9]ﾀﾞｲｵｰﾄﾞ
54	0CWE77002373A	AL	EB		B	IC (TC74HC373AF) [IC1]IC
55	0CWE74269BK28	AD	DJ		B	IC socket (2-641605-3) [for IC12]ICｿｹｯﾄ
56	0CWE7700214A／	AG	DX		B	IC (TC74HC14AF) [IC4]IC
57	0CWE7702006／／	AG	DS		B	IC (HD74LS06PF) [IC5]IC
58	0CWE321000320	AK	DX		B	IC (M51953BFP) [IC6]IC
59	0CW2198P422A／	AY	FQ		B	LSI (LSI-LC93043A-V54) [IC7]LSI
60	0CWE321000358	AG	DX		B	IC (UPC339G2) [IC9]IC
61	0CWE321000650	BB	GD		B	IC (STK681-050) [IC10]IC
62	0CWE323000280	BC	GJ		B	IC (uPD78233GC-3B9) [IC11]IC
63	0CWE321000591	AF	DS		B	IC (uPC358G2) [IC13,IC14]IC
64	0CWE230000031	AK	DX		C	Coil (SK-8MS-5Y) [L1,L2]ｺｲﾙ
65	0CWE314000337	AB	DD		B	LED (GL3PR8) [LED1]LED
66	0CWE250000107	AX	FX		B	Crystal (CST9.83MTW) [OSC1]ｸﾘｽﾀﾙ
67	0CWE250000141	AG	DX		B	Ceramic resonator (CST5.0MGW040) [OSC2]ｸﾘｽﾀﾙ
68	0CWE120000897	AD	DJ		B	Push switch (SKHHPK) [PSW1]ﾌﾟｯｼｭｽｲｯﾁ
69	0CWE312001240	AC	DD		B	Transistor (FN1L3N) [Q1,Q2]ﾄﾗﾝｼﾞｽﾀｰ
70	0CWE312000082	AC	DJ		B	Transistor (2SC2712) [Q3~Q5]ﾄﾗﾝｼﾞｽﾀｰ
71	0CWE312001081	AB	DD		B	Transistor (FA1L3N) [Q7~Q11]ﾃﾞｼﾞﾀﾙﾄﾗﾝｼﾞｽﾀｰ
72	0CWE312001363	AG	DX		B	FET (2SK1726) [Q14]FET
73	0CWE70188J223	AA	DJ		C	Resistor (CRG10GJ223J) [R1~R5,R78,R79]ﾃｲｺｳ
74	0CWE70228J103	AA	DJ		C	Resistor (RK73K1JTD 10KΩ J) [R6~R24]ﾃｲｺｳ
	0CWE70228J103	AA	DJ		C	Resistor (RK73K1JTD 10KΩ J) [R26~R28,R30,R32~R38]ﾃｲｺｳ
	0CWE70228J103	AA	DJ		C	Resistor (RK73K1JTD 10KΩ J) [R40~R43,R64,R69,R70,R75,R86]ﾃｲｺｳ
	0CWE70228J103	AA	DJ		C	Resistor (RK73K1JTD 10KΩ J) [R87,R96,R102~R104,R109~R111,R117]ﾃｲｺｳ
75	0CWE70188J104	AA	DJ		C	Resistor (CRG10G104J) [R45,R46,R48,R49]ﾃｲｺｳ
76	0CWE70188J100	AA	DJ		C	Resistor (CRG10G100J) [R50]ﾃｲｺｳ
77	0CWE70228J472	AA	DJ		C	Resistor (RK73K1JTD4.7KΩJ) [R31,R51~R62,R65,R68]ﾃｲｺｳ
	0CWE70228J472	AA	DJ		C	Resistor (RK73K1JTD4.7KΩJ) [R71~R73,R76,R77]ﾃｲｺｳ
78	0CWE70188J102	AA	DJ		C	Resistor (CRG10G102J) [R82,R83,R88]ﾃｲｺｳ
79	0CWE70188J105	AA	DJ		C	Resistor (CRG10G105J) [R90]ﾃｲｺｳ
80	0CWE70188J821	AA	DJ		C	Resistor (CRG10G821J) [R91]ﾃｲｺｳ
81	0CWE70197J4R7	AA	DJ		C	Resistor (ERD25FAJ4R7) [R44,R92]ﾃｲｺｳ
82	0CWE70188J202	AA	DJ		C	Resistor (CRG10G202J) [R80,R81]ﾃｲｺｳ
83	0CWE70188J153	AA	DJ		C	Resistor (CRG10G153J) [R29,R115]ﾃｲｺｳ
84	0CWE70188J152	AA	DJ		C	Resistor (CRG10G152J) [R63,R89]ﾃｲｺｳ
85	0CWE70188J302	AA	DJ		C	Resistor (CRG10G302J) [R74,R95]ﾃｲｺｳ
86	0CWE70205J332	AA	DJ		C	Resistor (CRG2G332J) [R108]ﾃｲｺｳ
87	0CWE70188J222	AA	DJ		C	Resistor (CRG10GJ222T) [R84]ﾃｲｺｳ
89	0CWE120000368	AR	EQ		B	Dip switch (KSD05) [SW1]ﾃﾞｨｯﾌﾟｽｲｯﾁ
90	0CWE76005A6R2	AE	DS		B	Zener diode (RD6.2FB) [ZD1]ﾂｪﾅｰﾀﾞｲｵｰﾄﾞ
91	0CWE76008H120	AB	DD		B	Zener diode (RD12MB2) [ZD2]ﾂｪﾅｰﾀﾞｲｵｰﾄﾞ
97	0CW2234K213／／	AY	FQ		B	EP ROM ass'y -NMI [IC2]EP ROMｸﾐ-NMI
98	0CWE70014J101	AB	DJ		C	Resistor (RD25S 100ΩJ) ﾃｲｺｳ
99	0CWE70188J912	AA	DJ		C	Resistor (CRG10G912J) [R66]ﾃｲｺｳ
100	0CWE73425M477	AD	DJ		C	Capacitor CEDSM1A471M-F [C58]ｺﾝﾃﾞﾝｻ
101	0CWE120001516	AF	DS	N	B	IC protector (ICP-N25) [ICP1]ICﾌﾟﾛﾃｸﾀｰ
102	0CWE321000540	AW	FG	N	B	IC (SI-8201L) [IC15]IC
	ﾕﾆｯﾄ (Unit)					
901	0CW2234K222／／	CA	TX	N	E	PBA control PWB PBA-ｺﾝﾄﾛｰﾙｷﾊﾞﾝ

■ 索引 (Index)

PARTS CODE	JAPAN ONLY ORDER CODE	NO.	PRICE R. Ex.	PRICE R. Ja.	NEW	P/R
【L】						
LX-BZ0776FCZZ	572 970 1677	8- 5	AG	DS		C
【P】						
PCÖVP0911FCZ1	572 323 1715	8- 1	AC	DJ		D
PCÖVP0941FCZ1	572 323 1716	8- 2	AC	DJ		D
【X】						
XBTSC50P16000	572 970 1529	8- 4	AA	DD		C
XRESP20-04000	507 399 5004	1- 39	AA	DD		C
XRESP30-05000	571 399 0017	3- 61	AA	DD		C
XRESP40-06000	509 399 5001	3- 97	AA	DD		C
〃	509 399 5001	4- 49	AA	DD		C
XRESP50-06000	572 399 0063	3- 46	AA	DD		C
〃	572 399 0063	5- 43	AA	DD		C
XRESP70-08000	571 399 0027	2- 18	AA	DD		C
〃	571 399 0027	3- 49	AA	DD		C
〃	571 399 0027	5- 36	AA	DD		C
XRESP80-09000	572 399 0057	3- 54	AA	DD		C
【0】						
0CW020050FZSA	572 970 1656	4- 84	AB	DJ		C
0CW023120FBWS	572 970 1733	1- 42	AB	DJ		C
〃	572 970 1733	5- 63	AB	DJ		C
0CW023140FBWS	572 970 1787	3- 80	AC	DJ		C
0CW030030FNiT	572 970 1798	1- 70	AB	DJ		C
〃	572 970 1798	3- 96	AB	DJ		C
0CW030030FZiT	572 970 1657	3- 81	AB	DJ		C
0CW030040FZBi	572 970 1198	4- 41	AA	DD		C
〃	572 970 1198	5- 52	AA	DD		C
0CW030040FZiT	572 970 0882	4- 47	AA	DD		C
0CW030040FZWS	572 970 0889	4- 38	AA	DD		C
0CW030060FNBi	572 970 1351	4- 43	AA	DJ		C
〃	572 970 1351	7- 18	AA	DJ		C
0CW030060FNTP	572 970 1659	2- 19	AB	DJ		C
0CW030060FZBi	572 970 1199	4- 34	AA	DD		C
〃	572 970 1199	5- 34	AA	DD		C
0CW030060FZBP	572 970 0946	4- 37	AA	DD		C
〃	572 970 0946	5- 50	AA	DD		C
0CW030060FZiT	572 970 0947	2- 41	AA	DD		C
〃	572 970 0947	3- 67	AA	DD		C
0CW030060FZSW	572 970 0951	2- 15	AA	DD		C
〃	572 970 0951	5- 35	AA	DD		C
0CW030060FZTP	572 970 0952	1- 34	AA	DD		C
〃	572 970 0952	2- 17	AA	DD		C
〃	572 970 0952	3- 63	AA	DD		C
〃	572 970 0952	4- 40	AA	DD		C
〃	572 970 0952	5- 40	AA	DD		C
0CW030060FZWS	572 970 0953	1- 38	AA	DD		C
〃	572 970 0953	2- 22	AA	DD		C
0CW030080FPWP	572 970 1391	3- 65	AB	DJ		C
0CW030080FZBB	572 970 1623	1- 46	AB	DJ		C
〃	572 970 1623	4- 33	AB	DJ		C
〃	572 970 1623	5- 59	AB	DJ		C
〃	572 970 1623	7- 15	AB	DJ		C
〃	572 970 1623	7- 28	AB	DJ		C
0CW030080FZWS	572 970 0960	2- 20	AA	DD		C
〃	572 970 0960	3- 71	AA	DD		C
0CW030100FBBB	572 970 1644	1- 48	AB	DJ		C
〃	572 970 1644	7- 20	AB	DJ		C
〃	572 970 1644	7- 30	AB	DJ		C
0CW030100FZBi	572 970 1202	4- 42	AA	DD		C
0CW040040FZiT	572 970 0938	1- 33	AA	DD		C
0CW040060FNBi	572 970 0988	1- 37	AA	DD		C
0CW040060FPWP	572 970 1208	1- 41	AA	DD		C
0CW040060FZBP	572 970 1645	3- 77	AB	DJ		C
0CW040060FZTP	572 970 1002	1- 32	AA	DD		C
0CW040060FZWS	572 970 1003	1- 63	AA	DD		C
0CW040080FNBi	572 970 1209	1- 35	AA	DD		C
0CW040080FZBi	572 970 1010	1- 40	AA	DD		C
〃	572 970 1010	5- 48	AA	DD		C
0CW040100FPWP	572 970 1646	5- 55	AC	DJ		C
0CW1001P441//	572 271 0498	1- 44	AG	DX		C
〃	572 271 0498	3- 51	AG	DX		C
0CW2078P023B/	572 970 1392	2- 21	AC	DJ		C
〃	572 970 1392	3- 52	AC	DJ		C
〃	572 970 1392	4- 39	AC	DJ		C
0CW2078P086B/	572 970 1216	4- 46	AB	DD		C
〃	572 970 1216	5- 38	AB	DD		C
0CW2078P119B/	572 970 1217	1- 71	AB	DD		C
〃	572 970 1217	4- 70	AB	DD		C
0CW2078P652//	572 970 1647	3- 82	AE	DS		C

PARTS CODE	JAPAN ONLY ORDER CODE	NO.	PRICE R. Ex.	PRICE R. Ja.	NEW	P/R
0CW2088P034//	572 230 0421	3- 83	AK	EB		C
0CW2094P090A/	572 271 0223	5- 47	AH	DX		B
0CW2095P053//	572 217 0059	1- 50	AE	DJ		C
0CW2095P310//	572 230 0422	3- 84	AD	DJ		C
0CW2106P091//	572 970 1737	1- 36	AC	DJ		C
0CW2107P032//	572 271 0458	5- 54	AN	EG		C
0CW2111P021//	572 906 0086	8- 17	AC	DJ		D
0CW2129P188//	572 214 1664	3- 89	AD	DJ		C
〃	572 214 1664	4- 44	AD	DJ		C
0CW2142P037//	572 284 0552	3- 79	AS	EQ		C
0CW2142P180//	572 281 1420	7- 17	AE	DS		C
0CW2144P409//	572 970 1738	1- 69	AB	DJ		C
0CW2147P033//	572 251 0048	5- 44	AD	DJ		C
0CW2148P093A/	572 906 0020	8- 15	AE	DS		D
0CW2158P003D/	572 248 0974	1- 53	AF	DS		C
〃	572 248 0974	3- 58	AF	DS		C
〃	572 248 0974	5- 39	AF	DS		C
0CW2158P005A/	572 218 0312	5- 42	AD	DJ		C
0CW2158P009A/	572 251 0022	5- 41	AD	DJ		C
0CW2158P035A/	572 318 0316	2- 34	AD	DJ		C
0CW2158P348A/	572 352 0193	4- 90	AD	DJ		C
0CW2158P377//	572 970 1573	3- 69	AB	DJ		C
〃	572 970 1573	4- 36	AB	DJ		C
0CW2158P380//	572 902 1122	8- 14	AE	DJ		D
0CW2158P504//	572 352 0281	1- 62	AK	EB		C
0CW2158P521B/	572 272 0559	3- 53	AE	DJ		C
〃	572 272 0559	5- 46	AE	DJ		C
0CW2160P344//	572 272 0560	2- 29	AR	EQ		B
0CW2164P142//	572 272 0500	2- 27	AF	DS		C
0CW2166P034B/	572 317 0005	3- 55	AC	DJ		C
0CW2166P265//	572 352 0256	1- 52	AF	DS		C
0CW2168P010//	572 318 0407	1- 55	AF	DS		C
0CW2168P029//	572 281 1310	3- 75	AF	DS		C
0CW2168P030//	572 284 0553	3- 78	AG	DX		C
0CW2180P333//	572 970 1775	1- 65	AC	DJ		C
0CW2185P023//	572 284 0559	2- 30	AE	DS		B
0CW2185P358//	572 970 1739	1- 47	AB	DJ		C
0CW2185P359//	572 970 1649	1- 45	AB	DJ		C
0CW2198K239//	572 512 0356	3- 95	AG	DX		C
〃	572 512 0356	5- 75	AG	DX		C
0CW2198P003//	572 284 0519	3- 66	AH	DX		C
0CW2198P302//	572 400 0468	4- 45	AD	DJ		C
0CW2198P305//	572 258 2300	2- 46	AH	DX		C
0CW2198P422A/	572 573 1188	9- 59	AY	FQ		B
0CW2199P117//	572 258 2296	7- 16	AE	DS		C
0CW2199P368//	572 326 0283	4- 35	AD	DJ		C
0CW2205P025//	572 413 0601	2- 36	AD	DJ		C
0CW2205P035//	572 214 1590	4- 82	AF	DS		C
0CW2205P037//	572 214 1591	2- 35	AE	DJ		C
0CW2205P042//	572 318 0432	1- 68	AD	DJ		C
0CW2205P050//	572 318 0408	4- 72	AD	DJ		C
0CW2205P051//	572 272 0541	4- 80	AE	DJ		B
0CW2205P052//	572 272 0542	4- 78	AE	DJ		C
0CW2205P147//	572 258 2521	2- 37	AC	DJ		C
〃	572 258 2521	2- 38	AC	DJ		C
0CW2205P152//	572 203 0393	4- 85	AK	EB		C
0CW2205P153//	572 231 0321	4- 73	AF	DS		C
0CW2205P351//	572 287 1517	2- 33	AU	EZ		C
0CW2205P360//	572 258 2522	2- 26	AD	DJ		C
0CW2214K002//	572 221 5666	5- 18	AW	FG		C
0CW2214K004//	572 221 5667	5- 5	AR	EQ		C
0CW2214K027E/	572 221 5935	3- 45	AX	FG		C
〃	572 221 5935	4- 27	AX	FG		C
0CW2214K032//	572 203 0356	4- 15	AK	EB		C
0CW2214K033//	572 203 0357	3- 42	AL	EB		C
0CW2214K054//	572 221 5669	1- 8	AH	DX		C
0CW2214K058//	572 902 1175	8- 6	BB	GD		D
0CW2214K101//	572 221 5724	3- 85	AL	EB		C
0CW2214K113//	572 970 1740	8- 3	AD	DJ		C
0CW2214K116//	572 403 4088	4-501	AH	DX		E
0CW2214K200//	572 542 0609	1- 20	AP	EQ		C
0CW2214K201//	572 542 0610	4- 2	AP	EQ		C
0CW2214K202E/	572 226 0498	7- 7	AS	EQ		C
0CW2214K203//	572 542 0612	1- 21	AN	EG		C
0CW2214K204//	572 542 0613	3- 4	AH	DX		C
0CW2214K205//	572 542 0614	1- 30	AL	EB		C
0CW2214K206//	572 542 0615	1- 22	AN	EG		C
0CW2214K207//	572 542 0616	4- 32	AM	EG		C
0CW2214K208//	572 512 0332	1- 19	AS	EQ		C
0CW2214K209//	572 512 0333	3- 2	AR	EQ		C
0CW2214K210//	572 542 0804	5- 70	AT	EZ		C

PARTS CODE	JAPAN ONLY ORDER CODE	NO.	PRICE R. Ex.	PRICE R. Ja.	NEW	P/R
0CW2214K211//	572 542 0617	5- 14	AL	EB		C
0CW2214K214//	572 542 0620	4- 14	AG	DX		C
0CW2214K216//	572 542 0622	3- 32	AH	DX		C
0CW2214K217//	572 542 0805	1-501	AU	EZ		C
0CW2214K222//	572 684 2537	5- 24	AS	EQ		E
0CW2214K223//	572 684 2538	1- 31	AU	EZ		E
0CW2214K224//	572 684 2539	4- 12	AS	EQ		E
0CW2214K240//	572 542 1201	1- 7	BE	GN		B
0CW2214K326//	572 110 1014	1- 1	BS	MJ		E
0CW2214K344//	572 246 0350	1- 3	BD	GN		E
0CW2214P004//	572 281 1293	7- 3	AF	DS		C
0CW2214P005//	572 214 1572	7- 2	AG	DS		C
0CW2214P007//	572 345 2473	3- 18	AT	EZ		C
0CW2214P009//	572 345 2474	4- 18	AX	FG		C
0CW2214P011//	572 345 2476	5- 30	AQ	EQ		C
0CW2214P012//	572 345 2477	5- 25	AR	EQ		C
0CW2214P019//	572 290 1923	3- 16	AP	EQ		C
0CW2214P020//	572 248 0888	3- 17	AE	DJ		C
0CW2214P021//	572 248 0889	3- 23	AE	DJ		C
0CW2214P022//	572 251 0043	3- 29	AE	DJ		C
0CW2214P023B/	572 248 0922	3- 20	AE	DJ		C
0CW2214P030//	572 248 0891	4- 17	AE	DJ		C
0CW2214P031//	572 284 0538	3- 41	AF	DS		C
0CW2214P032//	572 281 1294	3- 44	AF	DS		C
0CW2214P033//	572 318 0396	5- 28	AE	DJ		C
0CW2214P035C/	572 211 0598	4- 23	AF	DS		C
0CW2214P036//	572 251 0044	3- 21	AE	DS		C
0CW2214P037//	572 345 2479	3- 1	AH	DX		C
0CW2214P039//	572 214 1573	7- 4	AG	DS		C
0CW2214P042//	572 413 0588	2- 6	AD	DJ		C
0CW2214P043//	572 413 0589	2- 3	AD	DJ		C
0CW2214P044//	572 345 2480	2- 4	AF	DS		C
0CW2214P046//	572 323 1490	5- 67	AE	DS		C
0CW2214P051//	572 214 1592	2- 28	AD	DJ		C
0CW2214P059//	572 345 2931	7- 13	AK	DX		C
0CW2214P060//	572 345 2932	7- 14	AK	DX		C
0CW2214P061//	572 345 2933	4- 5	AY	FQ		C
0CW2214P062//	572 110 1015	4- 21	BA	FX		C
0CW2214P063//	572 345 2943	4- 26	AV	FG		C
0CW2214P064//	572 110 1016	5- 26	AX	FG		C
0CW2214P065//	572 110 1017	7- 1	AZ	FX		C
0CW2214P066//	572 226 0525	7- 11	BA	FX		D
0CW2214P067//	572 345 2934	4- 20	AU	FG		C
0CW2214P068//	572 110 1018	1- 23	AM	EG		D
0CW2214P070//	572 248 1043	7- 19	AH	DX		C
〃	572 248 1043	7- 24	AH	DX		C
0CW2214P101//	572 203 0358	3- 25	AE	DJ		C
0CW2214P102//	572 203 0359	4- 1	AE	DJ		C
0CW2214P103//	572 323 1471	4- 29	AD	DJ		C
〃	572 323 1471	5- 66	AD	DJ		C
0CW2214P104F/	572 221 6805	3- 28	AR	EQ		C
〃	572 221 6805	4- 10	AR	EQ		C
0CW2214P108//	572 203 0360	3- 6	AT	EZ		C
0CW2214P109//	572 203 0361	3- 12	AE	DS		C
0CW2214P110//	572 203 0362	1- 10	AL	EB		C
0CW2214P111//	572 221 5672	2- 2	AS	EQ		C
0CW2214P112//	572 221 5673	2- 13	AW	FG		C
0CW2214P113//	572 203 0363	5- 1	AF	DS		C
0CW2214P114//	572 373 0098	2- 1	AK	DX		C
0CW2214P116//	572 221 5674	1- 29	AE	DJ		C
0CW2214P117//	572 221 5675	1- 15	AF	DS		C
0CW2214P118B/	572 231 0331	2- 10	AM	EG		C
0CW2214P120//	572 203 0364	5- 11	AQ	EQ		C
0CW2214P124//	572 258 2464	5- 31	AE	DJ		C
0CW2214P126//	572 258 2466	1- 14	AG	DX		C
0CW2214P127//	572 323 1472	1- 2	AR	EQ		C
0CW2214P128//	572 203 0365	7- 6	AK	DX		C
0CW2214P129//	572 258 2467	7- 12	AF	DS		C
0CW2214P130//	572 221 5676	5- 29	AP	EQ		C
0CW2214P131//	572 203 0366	4- 8	AG	DX		C
0CW2214P132D/	572 231 0332	4- 7	AM	EG		C
0CW2214P134//	572 203 0367	4- 13	AF	DS		C
0CW2214P135//	572 221 5677	1- 18	AE	DJ		C
0CW2214P136//	572 258 2468	1- 28	AG	DS		C
0CW2214P138//	572 221 5678	2- 5	AH	DX		C
0CW2214P139//	572 221 5679	2- 14	AH	DX		C
0CW2214P140//	572 221 5680	1- 26	AE	DJ		C
0CW2214P141//	572 258 2469	2- 9	AH	DX		C
0CW2214P143C/	572 345 2595	5- 16	AP	EQ		C
0CW2214P144//	572 203 0394	4- 62	AF	DS		C
0CW2214P146//	572 217 0060	5- 65	AD	DJ		C

PARTS CODE	JAPAN ONLY ORDER CODE	NO.	PRICE R. Ex.	PRICE R. Ja.	NEW	P/R
0CW2214P149//	572 514 0066	2- 43	AG	DX		C
0CW2214P154D/	572 258 2862	4- 60	AH	DX		C
0CW2214P155//	572 120 0039	4- 9	AG	DX		C
0CW2214P157//	572 258 2523	2- 39	AK	DX		C
0CW2214P200//	572 290 1924	3- 33	AZ	FQ		C
0CW2214P201//	572 290 1925	3- 35	AV	FG		C
0CW2214P205//	572 290 1926	3- 15	AK	EB		C
0CW2214P206//	572 290 1927	3- 14	AP	EQ		C
0CW2214P208//	572 290 1928	5- 32	AD	DJ		C
0CW2214P209//	572 290 1929	5- 27	AE	DJ		C
0CW2214P300D/	572 407 0083	3- 36	AU	FG		C
0CW2214P301//	572 287 1479	3- 31	BB	GD		C
0CW2214P302//	572 287 1480	3- 30	AX	FG		C
0CW2214P303//	572 970 1620	4- 22	AD	DJ		C
0CW2214P306//	572 310 0218	4- 25	AV	FG		B
0CW2214P307//	572 400 0514	4- 19	AD	DJ		C
0CW2214P311//	572 258 2470	4- 16	AF	DS		C
0CW2214P312//	572 258 2471	3- 27	AD	DJ		C
0CW2214P313//	572 258 2472	3- 26	AD	DJ		C
0CW2214P314//	572 258 2473	3- 19	AD	DJ		C
0CW2214P315//	572 290 1930	1- 11	AR	EQ		C
0CW2214P316//	572 281 1295	3- 7	AS	EQ		C
0CW2214P317//	572 281 1296	3- 38	AS	EQ		C
0CW2214P318//	572 271 0445	3- 39	AR	EQ		B
0CW2214P319//	572 271 0446	3- 13	AP	EQ		B
0CW2214P320//	572 271 0447	3- 40	AQ	EQ		B
0CW2214P321//	572 287 1481	2- 31	BB	GD		C
0CW2214P322//	572 287 1482	2- 12	BB	GD		C
0CW2214P323//	572 287 1483	5- 13	AV	FG		C
0CW2214P328//	572 284 0539	5- 37	AS	EQ		C
0CW2214P331//	572 287 1485	5- 21	BD	GN		C
0CW2214P332//	572 258 2474	5- 20	AV	FG		C
0CW2214P335//	572 258 2475	5- 69	AD	DJ		C
0CW2214P339//	572 287 1486	3- 34	BA	FX		C
0CW2214P340//	572 284 0540	3- 10	AV	FG		C
0CW2214P341//	572 271 0448	3- 9	AP	EQ		C
0CW2214P342//	572 281 1297	3- 43	AS	EQ		C
0CW2214P343//	572 403 3554	4- 3	AE	DJ		C
0CW2214P344//	572 403 3555	4- 24	AE	DJ		C
0CW2214P347//	572 352 0266	5- 17	AD	DJ		C
0CW2214P348//	572 284 0541	5- 8	AX	FG		C
0CW2214P349//	572 284 0542	5- 6	AN	EQ		C
0CW2214P350//	572 258 2476	1- 9	AD	DJ		C
0CW2214P352//	572 400 0515	5- 33	AD	DJ		C
0CW2214P358//	572 970 1650	8- 13	AB	DJ		D
0CW2214P376//	572 403 3618	4- 86	AH	DX		C
0CW2214P377C/	572 310 0234	5- 15	AS	EZ		B
0CW2214P381//	572 403 3567	5- 22	AD	DJ		C
0CW2214P383//	572 403 3619	5- 68	AE	DJ		C
0CW2214P384//	572 902 1177	8- 10	AP	EQ		D
0CW2214P387//	572 403 3781	5- 71	AE	DS		C
0CW2214P391//	572 258 2525	4- 81	AG	DS		C
0CW2214P392//	572 258 2526	4- 83	AG	DS		C
0CW2214P393//	572 373 0103	2- 24	AG	DX		B
〃	572 373 0103	2- 25	AG	DX		B
0CW2214P402//	572 647 0264	5- 3	AU	FG		B
0CW2214P403//	572 647 0265	3- 24	AY	FQ		B
0CW2214P405//	572 424 0108	3- 3	AD	DJ		C
0CW2214P406//	572 424 0109	4- 31	AD	DJ		C
0CW2214P453//	572 403 3620	1- 51	AD	DJ		C
0CW2214P454//	572 403 3782	4- 89	AD	DJ		C
0CW2214P455//	572 258 2505	4- 57	AE	DS		C
〃	572 258 2505	5- 53	AE	DS		C
0CW2214P456B/	572 704 0043	3- 73	AG	DX		C
0CW2214P458//	572 400 0531	4- 59	AG	DX		C
0CW2214P459//	572 400 0532	5- 58	AD	DJ		C
0CW2214P460//	572 400 0533	5- 60	AD	DJ		C
0CW2214P462//	572 287 1518	2- 11	AZ	FQ		C
0CW2214P464//	572 400 0534	5- 57	AE	DJ		C
0CW2214P465//	572 403 3783	5- 72	AM	EG		C
0CW2214P466//	572 400 0535	5- 61	AG	DX		C
0CW2214P469//	572 400 0536	3- 72	AE	DJ		C
0CW2214P470//	572 902 1178	8- 7	AH	DX		D
0CW2214P471//	572 287 1519	3- 56	AQ	EQ		C
0CW2214P472//	572 400 0537	5- 64	AP	EQ		C
0CW2214P477//	572 352 0268	4- 54	AH	DX		C
0CW2214P485//	572 258 2527	4- 69	AD	DJ		C
0CW2214P489//	572 403 3624	1- 60	AH	DX		C
0CW2214P490//	572 330 0008	1- 61	AG	DX		C
0CW2214P491//	572 403 3625	3- 76	AH	DX		C
0CW2214P492//	572 403 3626	3- 88	AH	DX		C

PARTS CODE	JAPAN ONLY ORDER CODE	NO.	PRICE R. Ex.	PRICE R. Ja.	NEW	P/R
0CW2214P493//	572 403 3627	4- 87	AG	DS		C
0CW2214P494//	572 403 3628	4- 66	AD	DJ		C
0CW2214P496//	572 403 3629	1- 58	AE	DJ		C
0CW2214P497//	572 403 3630	1- 59	AE	DJ		C
0CW2214P498//	572 326 0313	1- 64	AE	DJ		C
0CW2214P512//	572 323 1491	1- 54	AG	DX		C
0CW2214P513//	572 258 2477	1- 16	AG	DS		C
0CW2214P520//	572 214 1593	2- 40	AU	EZ		C
0CW2214P521//	572 403 4021	4- 58	AF	DS		C
0CW2214P524//	572 403 4074	3- 87	AG	DS		C
0CW2214P528//	572 403 4089	3- 93	AC	DJ		C
0CW2214P529//	572 970 1788	5- 51	AC	DJ		C
0CW2214P531//	572 413 0652	3- 91	AC	DJ		C
0CW2214P541//	572 917 3213	7- 22	AD	DJ		C
0CW2214P542//	572 156 0800	7- 23	AR	EQ		D
0CW2214P544//	572 156 0801	7- 23	AN	EG		D
0CW2214P545//	572 156 0796	7- 23	AR	EQ		D
0CW2214P546//	572 156 0797	7- 23	AV	FG		D
0CW2214P569//	572 970 1799	2- 44	AB	DJ		C
0CW2214P575//	572 271 0612	2- 7	BR	LP	N	B
0CW2217P135//	572 221 6620	1- 29	AG	DS		C
0CW2221P336//	572 352 0282	1- 56	AU	EZ		C
〃	572 352 0282	5- 56	AU	EZ		C
0CW2223K214//	572 542 1043	7- 5	AX	FG		C
0CW2223P101//	572 514 0067	3- 90	AD	DJ		C
0CW2223P102//	572 120 0085	4- 68	AH	DX		C
0CW2223P404//	572 630 0905	1- 12	BN	HZ		B
0CW2224P333//	572 158 0571	1- 49	AN	EG		D
0CW2224P334//	572 158 0572	1- 49	AS	EQ		D
0CW2231K064//	572 287 1710	4- 79	AY	FQ		C
0CW2234K034//	572 246 0349	1- 17	BD	GN		E
0CW2234K176//	572 290 2491	4-502	AU	FG	N	E
0CW2234K181//	572 290 2492	4-502	AX	FG	N	E
0CW2234K202//	572 542 1044	7- 7	AT	EZ		C
0CW2234K203//	572 542 1203	1- 78	AG	DS		C
0CW2234K213//	572 573 1646	9- 97	AY	FQ		B
0CW2234K222//	572 684 3378	9-901	CA	TX	N	E
〃	572 684 3378	1- 27	CA	TX	N	E
0CW2234P008//	572 326 0351	3- 86	AG	DX		C
0CW2234P104//	572 230 0467	1- 5	AG	DS		C
0CW2234P301//	572 248 1023	3- 92	AF	DS		C
0CW2234P322//	572 352 0296	4- 63	AH	DX		C
0CW2234P330//	572 901 1565	8- 12	BC	GJ	N	D
0CW2234P331//	572 901 1566	8- 12	BC	GD	N	D
0CW2234P334//	572 913 0899	8- 8	AQ	EQ	N	D
0CW2234P335//	572 403 4499	5- 73	AG	DS	N	C
0CW2234P336//	572 403 4500	5- 74	AG	DS	N	C
0CW2234P400//	572 630 0906	5- 12	BK	HC		B
0CW2234P401//	572 630 0907	3- 5	BM	HR		B
0CW2234P410//	572 350 0022	2- 45	AR	EQ		C
0CW2235P039//	572 248 1042	7- 27	AG	DX		C
0CW319300////	572 272 0315	3- 48	AD	DJ		B
〃	572 272 0315	5- 4	AD	DJ		B
0CW338412////	572 970 1651	5- 62	AE	DS		B
0CW338422////	572 272 0325	3- 70	AB	DD		B
0CW338432////	572 272 0407	3- 59	AC	DD		B
0CW4016P167//	572 990 0460	2- 16	AC	DJ		C
〃	572 990 0460	3- 68	AC	DJ		C
〃	572 990 0460	4- 48	AC	DJ		C
〃	572 990 0460	5- 49	AC	DJ		C
0CW4054P074B/	572 203 0418	7- 26	AF	DS		C
0CW616371////	572 906 0067	8- 16	AA	DJ		D
0CW650593////	572 272 0499	2- 23	AU	EZ		B
0CW690381////	572 272 0410	3- 47	AE	DS		C
0CW812531////	572 970 1265	1- 43	AA	DD		C
0CWE120000368	572 530 0409	9- 89	AR	EQ		B
0CWE120000870	572 530 0493	1- 13	AM	EG		B
〃	572 530 0493	3- 37	AM	EG		B
〃	572 530 0493	5- 19	AM	EG		B
0CWE120000897	572 530 0494	9- 68	AD	DJ		B
0CWE120001516	572 577 0032	9-101	AF	DS	N	B
0CWE230000031	572 614 0180	9- 64	AK	DX		C
0CWE240000309	572 530 0600	1- 67	AP	EQ		B
0CWE240000356	572 615 0054	1- 79	AS	EQ		C
0CWE250000107	572 616 0042	9- 66	AX	FX		B
0CWE250000141	572 616 0066	9- 67	AG	DX		B
0CWE311000977	572 570 0302	9- 51	AB	DD		B
0CWE311000978	572 570 0303	9- 50	AD	DJ		B
0CWE311001019	572 570 0425	9- 53	AD	DJ		B
0CWE311001020	572 570 0426	9- 52	AE	DS		B
0CWE312000082	572 576 0419	9- 70	AC	DJ		B

PARTS CODE	JAPAN ONLY ORDER CODE	NO.	PRICE R. Ex.	PRICE R. Ja.	NEW	P/R
0CWE312001081	572 576 0311	9- 71	AB	DD		B
0CWE312001240	572 576 0315	9- 69	AC	DD		B
0CWE312001293	572 576 0438	9- 16	AR	EQ		B
0CWE312001310	572 576 0446	9- 18	AC	DJ		B
0CWE312001362	572 576 0439	9- 15	AC	DJ		B
0CWE312001363	572 576 0423	9- 72	AG	DX		B
0CWE312001368	572 576 0440	9- 17	AK	DX		B
0CWE314000120	572 574 0152	7- 9	AM	EG		B
〃	572 574 0152	7- 10	AM	EG		B
0CWE314000337	572 574 0231	9- 65	AB	DD		B
0CWE314000528	572 568 0023	4- 6	AL	EB		B
0CWE314000531	572 568 0024	3- 11	AN	EG		B
〃	572 568 0024	7- 25	AN	EG		B
0CWE321000320	572 573 1183	9- 58	AK	DX		B
0CWE321000358	572 573 0936	9- 60	AG	DX		B
0CWE321000540	572 573 1917	9-102	AW	FG	N	B
0CWE321000591	572 573 0800	9- 63	AF	DS		B
0CWE321000644	572 573 1309	9- 14	AZ	FQ		B
0CWE321000645	572 573 1310	9- 13	BB	GD		B
0CWE321000650	572 573 1185	9- 61	BB	GD		B
0CWE323000280	572 573 1186	9- 62	BC	GJ		B
0CWE323000343	572 573 1703	9- 12	AD	DJ		B
0CWE420001011	572 580 0762	9- 33	AC	DJ		C
0CWE450000005	572 201 0059	7- 31	AA	DD		C
0CWE450000067	572 214 1579	7- 21	AC	DJ		C
0CWE450000070	572 201 0104	1- 6	AB	DJ		C
0CWE450000071	572 214 1467	1- 25	AC	DJ		C
0CWE450000368	572 214 1569	1- 24	AD	DJ		C
〃	572 214 1569	7- 8	AD	DJ		C
〃	572 214 1569	7- 29	AD	DJ		C
0CWE450000433	572 214 1082	1- 4	AB	DD		C
〃	572 214 1082	4- 11	AB	DD		C
〃	572 214 1082	5- 9	AB	DD		C
0CWE450000574	572 201 0126	4- 61	AC	DJ		C
〃	572 201 0126	5- 2	AC	DJ		C
0CWE450000871	572 201 0123	3- 22	AB	DJ		C
〃	572 201 0123	4- 30	AB	DJ		C
〃	572 201 0123	5- 7	AB	DJ		C
0CWE450000896	572 214 1570	4- 4	AC	DJ		C
〃	572 214 1570	5- 10	AC	DJ		C
0CWE450000897	572 214 1571	3- 8	AC	DJ		C
〃	572 214 1571	4- 28	AC	DJ		C
0CWE70014J101	572 580 0763	9- 98	AB	DJ		C
0CWE70162J100	572 594 0656	9- 23	AA	DJ		C
0CWE70162J101	572 580 0818	9- 19	AA	DJ		C
0CWE70162J181	572 580 0819	9- 20	AA	DJ		C
0CWE70162J202	572 594 0657	9- 22	AA	DJ		C
0CWE70162J472	572 580 0820	9- 27	AA	DJ		C
0CWE70188F153	572 580 0821	9- 32	AA	DJ		C
0CWE70188F243	572 580 0824	9- 29	AA	DJ		C
0CWE70188F683	572 580 0825	9- 30	AA	DJ		C
0CWE70188F751	572 580 0840	9- 26	AA	DJ		C
0CWE70188F912	572 580 0826	9- 31	AA	DJ		C
0CWE70188J100	572 580 0719	9- 76	AA	DJ		C
0CWE70188J102	572 580 0721	9- 78	AA	DJ		C
0CWE70188J104	572 580 0723	9- 75	AA	DJ		C
0CWE70188J105	572 580 0724	9- 79	AA	DJ		C
0CWE70188J152	572 580 0725	9- 84	AA	DJ		C
0CWE70188J153	572 580 0726	9- 83	AA	DJ		C
0CWE70188J154	572 580 0827	9- 24	AA	DJ		C
0CWE70188J202	572 580 0727	9- 82	AA	DJ		C
0CWE70188J203	572 580 0728	9- 21	AA	DJ		C
0CWE70188J222	572 580 0730	9- 87	AA	DJ		C
0CWE70188J223	572 580 0781	9- 73	AA	DJ		C
0CWE70188J302	572 580 0907	9- 85	AA	DJ		C
0CWE70188J821	572 580 0792	9- 80	AA	DJ		C
0CWE70188J912	572 580 0974	9- 99	AA	DJ		C
0CWE70197J4R7	572 581 1634	9- 81	AA	DJ		C
0CWE70205J222	572 580 0829	9- 28	AC	DJ		C
0CWE70205J332	572 580 0975	9- 86	AA	DJ		C
0CWE70213JR39	572 580 0830	9- 25	AC	DJ		C
0CWE70228J103	572 580 1064	9- 74	AA	DJ		C
0CWE70228J472	572 580 1069	9- 77	AA	DJ		C
0CWE73268J101	572 594 0658	9- 3	AF	DS		C
0CWE73303Z104	572 594 0659	9- 41	AB	DJ		C
0CWE73303Z105	572 594 0660	9- 4	AD	DJ		C
0CWE73303Z224	572 594 0661	9- 8	AC	DJ		C
0CWE73303Z334	572 594 0700	9- 38	AC	DJ		C
0CWE73423M105	572 594 0669	9- 43	AC	DJ		C
0CWE73423M106	572 594 0662	9- 1	AC	DJ		C
0CWE73423M475	572 594 0663	9- 7	AC	DJ		C

PARTS CODE	JAPAN ONLY ORDER CODE	NO.	PRICE R.		NEW	P/R
			Ex.	Ja.		
0CWE73423M476	572 594 0664	9- 6	AC	DJ		C
0CWE73425M107	572 594 0670	9- 36	AD	DJ		C
0CWE73425M476	572 594 0708	9- 42	AC	DJ		C
0CWE73425M477	572 594 0723	9-100	AD	DJ		C
0CWE73431M107	572 594 0665	9- 5	AF	DS		C
0CWE73495K102	572 594 0764	9- 37	AB	DJ		C
0CWE73495K103	572 594 0765	9- 39	AB	DJ		C
0CWE73497Z104	572 594 0768	9- 2	AA	DJ		C
0CWE74071WE04	572 510 0647	9- 46	AC	DJ		C
0CWE74212WE06	572 510 0885	9- 9	AE	DJ		C
0CWE74212WE08	572 510 0886	9- 10	AE	DJ		C
0CWE74212WE09	572 510 0887	9- 11	AE	DS		C
0CWE74269BK28	572 573 0505	9- 55	AD	DJ		B
0CWE74299BK06	572 510 0418	9- 44	AB	DD		C
0CWE74382WE03	572 510 0963	1- 77	AL	EB		C
0CWE76005A6R2	572 571 0135	9- 90	AE	DS		B
0CWE76008G180	572 570 0423	9- 35	AD	DJ		B
0CWE76008H120	572 571 0056	9- 91	AB	DD		B
0CWE76008H160	572 570 0424	9- 34	AD	DJ		B
0CWE7700214A/	572 573 1176	9- 56	AG	DX		B
0CWE77002373A	572 573 1316	9- 54	AL	EB		B
0CWE7702006//	572 573 0518	9- 57	AG	DS		B
0CWHP020060SC	572 218 0400	3- 60	AC	DJ		C
0CWHP020100SC	572 218 0429	5- 45	AC	DJ		C
0CWHP020120SC	572 218 0403	3- 50	AC	DJ		C
0CWHP020140SC	572 218 0404	3- 57	AC	DJ		C
0CWHW030FZM//	572 990 0469	3- 94	AA	DJ		C
0CWSP030100FP	572 218 0534	3- 62	AC	DJ		C
0CWZ0030WE004	572 204 0352	2- 42	AC	DJ		C

PARTS CODE	JAPAN ONLY ORDER CODE	NO.	PRICE R.		NEW	P/R
			Ex.	Ja.		

SHARP

COPYRIGHT © 1999 BY SHARP CORPORATION

All rights reserved.
Printed in Japan.

No part of this publication may be reproduced,
stored in a retrieval system, or transmitted,
in any form or by any means,
electronic, mechanical, photocopying, recording, or otherwise,
without prior written permission of the publisher.

SHARP CORPORATION
Printing & Reprographic Systems Group
Quality & Reliability Control Center
Yamatokoriyama, Nara 639-1186, Japan
January 1999 Printed in Japan Ⓝ